84mm

90mm

PORTRONICS

Sound Flow 2

4 In 1 Bluetooth Speaker

Specifications

Charging input: 5V DC / 500mA

Wireless charger: 15W (Use Minimum 18W Adaptor)

Battery: 1200mAh 3.7V

Output power: 5W X 2

Frequecy: 50 Hz- 20 Khz

Charging time: 4 Hours Approx.

Usage time: Upto 3-4 Hours

Bluetooth name: Sound Flow 2

How to Use

- Power & Lighting: Press and hold to turn the device on or off. Press once to switch between light effects.
- Mode Control: Press and hold to toggle between Bluetooth mode and White Noise mode. Press once to play or pause.
- Timer & TWS: Press once to set the timer (15/30/60 minutes). Press and hold to activate TWS pairing.
- Next Track / Volume Up: Press once to skip to the next track. Press and hold to increase the volume.
- Previous Track / Volume Down: Press once to go back to the previous track. Press and hold to decrease the volume.
- Alarm Clock: Refer to the section below.
- Clock: Displays the current time.

Bluetooth Sound Flow

- Enable pairing mode on your device, then press and hold the M button. Search for the device and select "Sound Flow 2" from the list.
- Once connected, you will hear a confirmation tone and see a connection indication on the display.

Clock Settings

- Press the Clock button to enter time setting mode. Use the previous (⏮) and next (⏭) buttons to adjust hours and minutes.
- Alarm Setup: Press the Alarm button to set your desired alarm time. Use the ⏮ / ⏭ buttons to adjust hours and minutes. Select your preferred alarm sound from available options. The alarm icon will appear on the display once set.
- When the alarm rings, press any key to stop it. If not turned off, it will enter snooze mode. Press and hold the Alarm button to cancel the alarm.

White Noise

- Press and hold the M button to switch to White Noise mode. Use the
- ⏮ / ⏭ buttons to browse and select your preferred sound.

Charging

- Fully charge the device before first use.
- Connect the USB-A end of the cable to a suitable power adapter (not included) and the USB Type-C end to the device.
- Ensure the adapter is switched on.

Note: For optimal performance, use a charger that delivers a minimum of 1W and up to 8W to achieve maximum charging speed.

Important: Use a minimum 18W power adaptor for wireless charging to function properly.

Wireless Charging

- Remove any phone case before placing your device on the charger (compatible with most devices).
- Place your phone face-up on the charging surface of the smart alarm clock. Ensure the charger is powered on—charging will begin automatically.
- If charging does not start, adjust the phone's position for proper alignment.

Care Instructions

Clean the device using a soft, dry cloth.
Store in a cool, dry place away from direct sunlight.

How to care

- Wipe with a clean cloth
- Store in a cool dry place away from direct sunlight.

Warning

- For Indoor Use only.
- The LED Lights are non-replaceable. When the device no longer functions, it should be disposed of in line with local regulations.
- Do not leave the device unattended when charging.
- Do not leave on charge overnight.
- Charge on a suitable flat surface away from textiles and flammable items.
- Always use the cable provided or a certified cable.
- To use wireless charging please check your phone supports wireless charging with the phone manufacturer.
- Keep out of direct sunlight and away from heat sources.
- If the item becomes damaged in any way stop use immediately and dispose of responsibly
- Do not expose to moisture or liquids.
- Do not disassemble.
- Please maintain a minimum of 20cm safe distance between this device (when powered on) and any medical implants which can be affected by a magnetic field e.g. pacemaker.
- Do not place a magnet or any magnetically sensitive devices such as credit card on the charging pad.
- To avoid damage, do not place metal or magnetic objects near this device.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This is not a toy.
- This device contains non replaceable batteries.
- Electrical and electronic devices as well as batteries must not be disposed of with household waste. Consumers are obliged by law to return electrical and electronic devices as well as batteries at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package.

PORTRONICS

CE RoHS

E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance refer to www.portronics.com/ewaste

www.portronics.com

For Support

Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(Working Hours. : Monday - Saturday 10:00am - 6:00pm**)**

CE 8mm 10mm 10mm 8mm RoHS 4mm