



# AERO 10

## INTRODUCTION

Thank you for choosing the Portronics Aero 10 Power Bank. This 20W portable charger is designed to keep your smartphones powered on the go, featuring a sleek design and an easy-to-read LED indicator. This user manual will guide you through its features and proper usage. We appreciate your trust in Portronics!

## PACKAGE CONTAINS

- Powerbank X 1 N
- USB Charging Cable X 1 N
- User Manual X 1 N

## TECHNICAL SPECIFICATIONS


Battery : Li-Polymer  
 Battery Power : 38.5Wh 10000mAh  
 Input : Type-C1 ( 5V~3A, 9V~2A, 12V~1.5A )  
 Output : Type-C1 (5V~3A, 9V~2.22A, 12V~1.67A )  
 Type-C2 Cable (5V~3A, 9V~2.22A, 12V~1.67A )

## CHARGING THE POWER BANK

Connect one end of the charging cable to a power adapter and the other end to the power bank. The LED indicator will start blinking to show that charging is in progress.

## PROTECTION MODE (SAFETY FEATURE)

If the power bank detects abnormal conditions such as overcharging or over-discharging, it will automatically enter protection mode and stop functioning. To resume normal operation, connect the power bank to a charger and start charging again.




## CHARGING A PHONE

Connect one end of the charging cable to the power bank's output port and the other end to your phone. The LED indicator will turn on, indicating that charging has started.

## CHARGING OTHER DEVICES

- Connect one end of the charging cable to the power bank's output port.
- Connect the other end to the device you wish to charge (such as a tablet or other USB-powered device).
- The LED indicator will remain on while charging is in progress.



## SAFETY INSTRUCTIONS

### 1. STORAGE

- Store in a Safe Environment: Keep the power bank in a cool, dry place. Avoid direct sunlight, excessive heat (such as inside a parked car), or freezing temperatures.
- Partial Charge for Long-Term Storage: If not used for a long period, store the power bank at 50–60% charge.
- Avoid Moisture: Keep away from water or humid conditions to prevent short circuits or corrosion.

### 2. HANDLING & USAGE SAFETY

- Inspect Regularly: Stop using the power bank if you notice swelling, cracks, or exposed wires.
- Avoid Physical Impact: Do not drop, crush, or apply pressure.
- Keep Away from Metal Objects: Avoid contact with coins, keys, or metal items.
- Prevent Overheating: If it becomes unusually hot, unplug and allow it to cool.
- Do Not Disassemble: Never open or repair the power bank yourself.
- Do Not Keep in Pockets During Use: Avoid keeping the power bank in your pocket while it is operating. Always hold it in your hand or place it on a flat, open surface.

### 3. CHARGING INSTRUCTIONS

- Use Correct Cable & Charger: Use the provided or certified high-quality accessories only.
- Avoid Overcharging: Unplug once fully charged.
- Do Not Overcharge Overnight: Avoid leaving the power bank plugged in overnight.
- Do Not Charge & Discharge Simultaneously.
- Charge in a Safe Area: Place on a flat, non-flammable surface.

### 4. UNSAFE USAGE CONDITIONS

- Do not place on beds, cushions, or under pillows.
- Do not store in pockets or bags with metal objects.
- Keep away from heaters or radiators.
- Do not leave on car dashboards under sunlight.

### 5. LOAD & PERFORMANCE SAFETY

Do Not Overload: Connect only devices within the rated output capacity.

### 6. AIR TRAVEL SAFETY

- Carry power banks only in hand baggage.
- Do not charge devices using the power bank during flights.

### 7. FIRE SAFETY

- In Case of Fire: Use a Class D fire extinguisher or sand.
- Do Not Use Water.

### 8. DISPOSAL & RECYCLING

Dispose responsibly at authorized electronic waste recycling centers.

## HANDLING A SWOLLEN POWER BANK

If your power bank swells, stop using it immediately and unplug it carefully, placing it on a non-flammable surface away from flammable items, people, and pets to avoid risks like leaks or explosions. Do not puncture or open it; instead, let it cool down and dispose of it at an electronics recycling center per local rules—never in regular trash. Contact the manufacturer for further advice

## IMPORTANT NOTE

The company will not be responsible for any damage, injury, or malfunction resulting from improper usage, mishandling, or failure to follow the manufacturer's instructions