

AirCop

2-in-1 Vacuum and Blower for Quick, Effortless Cleaning



User Manual


SAFETY PRECAUTIONS

Please follow these guidelines to ensure safe usage:


- Do not use the device with wet hands.
- Keep the product away from water, splashes, or moisture.
- Do not block the air inlet or outlet during use.
- Do not insert any objects into the air inlet or outlet.
- Keep away from heat sources such as stoves or open flames.
- Do not use near flammable substances like petrol, gas, paint thinner, or sprays.
- Avoid dropping or hitting the product.
- Do not pull, twist, or damage the charging cable.
- Stop using the device immediately if it makes unusual noise, smell, or overheats.
- Do not open or disassemble the product. Contact customer support if needed.

PACKAGE CONTENTS

1. AirCop × 1N
2. Vacuum / Blower Nozzles × 4N
3. Type-C Cable × 1N
4. User Manual × 1N



PRODUCT OVERVIEW






SPECIFICATIONS

- Input Voltage : 5V
- Input Current : 2A
- Power : 150W
- Charging Port : Type-C

- Motor : Dual Brush less motor
- RPM : 1,30,000 RPM
- Suction Power : 16,000 PA

INSTALLING THE NOZZLES


- Align the nozzle with the opening.
- Insert gently until it fits securely.
- Do not block the air inlet or outlet while the device is running.



HOW TO USE

1. Power ON

- Press the Power Button to turn on the device.



2. Blower Function

- Press the Blower Button to activate airflow.
- Short press to cycle through 3 speed levels.

3. Vacuum Function

- Press the Vacuum Button to start suction.
- Short press again to switch between 2 speed levels.

- ⚠ Vacuum and blower cannot be used at the same time.
- Stop one function before switching to the other.

INDICATOR LIGHT GUIDE

- Green Light (Solid) : Device in use
- Red Light (Blinking) : Charging
- Red Light (Solid) : Fully charged
- Green Light (Blinking) : Low battery
- The device cannot be used while charging.

CARE & MAINTENANCE

- Clean the device using a soft, dry cloth only.
- Do not wash with water, alcohol, or chemical cleaners.
- Remove nozzles regularly and clean air inlet/outlet.
- Do not scratch the air vents with sharp objects.
- Avoid overcharging or deep discharging the battery.
- If the nozzle gets blocked, the device may shut off automatically to prevent overheating. Wait 30 seconds, clear the blockage, and restart.
- The battery is recyclable.
- Dispose of the battery only through authorized recycling centers.
- Battery removal should be done by professionals only.

TROUBLESHOOTING

1. Device not turning on?
 - Battery may be low. Please charge fully.
2. No indicator light while charging?
 - Check the power adapter and Type-C cable connection.