



APOLLO 20

25W Bluetooth Speaker With Dual Wireless Karaoke Mic



User Manual

INSTRUCTIONS

- Read Instructions:** All the instruction should be read carefully before operation and follow the instruction.
- Environment:** The speaker should be situated away from heat sources such as radiators, with proper ventilation, and not expose to moistair or water.
- Positioning:** Place the speakers on a stable surface and out of reach of children.
- Power Sources:** The speaker should be connected to a power supply only of the type described in the operating instruction or as marked on the speaker, using the accessories enclosed
- Electric Shock:** To avoid shock hazard, do not remove the cover or dismantle the unit, do not insert anything into the unit.
- Mending:** The user should not attempt to repair the speaker. Servicing should be referred to qualified service personnel or returned to the dealer or contact nearest Portronics Service Centre For assistance.


7. **Cleaning:** Disconnect the main plugs from the outlet before cleaning the unit. Only use soft cloth, no harsh abrasives or chemicals to clean, as it will damage the surface finishing.

8. **Non-Use Periods:** The power cord of the speaker should be unplugged from the outlet when left unused for a long period of time.


PACKAGE CONTENTS

- Party Speaker 1 N
- Charging Cable 1 N
- Wireless karaoke Mic 2 N
- User Manual 1 N

PRODUCT DETAILS



- ① Power On/Off
- ② Mode
- ③ Play/Pause
- ④ RGB Lights
- ⑤ Next/Volume +
- ⑥ Previous /Volume -
- ⑦ USB port
- ⑧ Type-C Charging Jack



BUTTON INSTRUCTIONS

BUTTONS	OPERATION	FUNCTIONS
	Long press	Power on/off
	Short press	Switching Mode
	Short press	Play/Pause Music;
	Short press	4 light modes
	Long press 2S	Turn off the lights
	Short press	Volume+
	Long press 2S	Next Song
	Short press	Volume-
	Long press 2S	Previous Song

SPECIFICATIONS:

Bluetooth version: V5.3
Speaker Size: 2.5 inch*2
RMS power output: 25W
Charge Voltage: DC 5V
Battery Capacity: 3.7V, 3600mAh
Frequency Response: 20Hz-20kHz
Bluetooth connecting range: > 10m
Product size: 260(L)*110(W)*120(H)MM

WIRELESS MICROPHONE INSTRUCTION

Turn on the Speaker and connect with Bluetooth mode . Turn on the Wireless Microphone to automatic connect the speaker, then enjoy your singing with the songs you play.

BUTTONS	OPERATION	FUNCTIONS
	Short press	Enter ECHO Adjustment Mode 1. Short press the Volume Up(+) /Down (-) Buttons to cycle through different echo intensity levels. 2. Short press the Power Button (⏻) again to save your settings and exit
	Long press 2S	Power On/off
	Short press	Volume+
	Long press 2S	Next Song
	Short press	Volume-
	Long press 2S	Previous Song
	Short press	5 modes Voice Changer Voice Cancellation
	Double Press	Double press to change RGB effect of Microphone and off RGB
	Type-C	DC 5V (Red light on)

BLUETOOTH CONNECTION

- When turned on for the first time, the speaker will automatically enter Bluetooth pairing mode and the blue light will flash. When pairing, turn on your Bluetooth device and search Apollo 20 for pairing
- When the connection is successful, the blue light turns to solid blue, and you will hear the connection tone.

RGB LIGHTS

Turn on the speaker with blue light. When you are connected to Bluetooth, there are 4 light modes to choose which can be switched by press the button on the top.
Mode 1: Individual seven-color light flow from left to right smoothly.
Mode 2: Individual seven-color light flow from left to right slowly.
Mode 3: Seven- color lights flow from left to right iteratively .
Mode 4: Seven- color lights flow from left to right.

CHARGING

For a better product experience, please fully charge the speaker before using it. The package contains a Type-C charging cable (only charging, no data transmission function), please use at least 5V/2A adapter.
Product damage may occur if a non-standard 5V adapter is used for charging. It is forbidden to charge if the charging cable is damaged or the device is wet.

ATTENTIONS

- Make sure not to disturb others.
- Do not close to chemicals such as benzene and thinner.
- Keep away from strong magnetic and electric fields.
- Keep away from direct lighting or heating equipment.
- Be sure not to disassemble, repair or modify the product by yourself.
- Battery power shortage will affect the Bluetooth range or Bluetooth connection. Please charge in time.
- For discarded packaging, batteries and old electronics, please dispose of them properly through classification.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste