PORTRONICS

APOLLO PLUS DUO


Bluetooth Speaker With Wireless Karaoke Mic




USER MANUAL

Package Contains :

1 × Apollo Plus Duo Speaker
1 × Wirless Karaoke Microphone
1 × Type C Cable
1 × AUX Cable
1 × User Manual



Speaker Functions :




Single press **M** button to change mode.
(Bluetooth,AUX,USB,TF)
Long press to ON/OFF or Change the RGB Effect.

Single press to previous track/Video.
Long press to reduce volume.

Single press to next track/Video.
Long press to increase volume.

Play and pause.



Mic Functions :

ON/OFF :

Long press power button to ON/OFF the Mic.

Mic ON - Blue on Mic turns ON.

ECHO CONTROL :

Long press VOL+ button to increase echo

Long press VOL- button to decrease echo

VOICE CHANGER :

Single press EFF button to change voice. By default it will start in normal voice.


Speaker beep once after changing the voice and beeps twice if it is in normal mode.

5 voice modes :

Normal -> Female to Male -> Baby -> Male to Female -> Monster.


Vocal Remover :

Long press EFF button to reduce vocals. Long press again to undo it.



Bluetooth Connection :

When turned ON, the speaker starts in the bluetooth mode. Blue LED blinks search for " Portronics Apollo Plus Duo " in your device and pair it, the blue LED becomes stable.



LED Indicators :

- Blue LED Blinks : * Pairing Mode
- Blue LED Stable : Paired
- RED LED : Charging
- RED LED OFF : Full Charged
- Low Battery Indication : Battery error sound prompts.

Product Specifications :

Modes : Bluetooth / AUX / USB /TF card
RGB Effects : 8 Effects
Bluetooth version : 6.0
Material : ABS body + iron mesh
Sound Output : 20W x 2
Charging Input : DC 5V/1A
Charging Port : Type C
Charging time : 4-5 hours
Battery Type Speaker : Li-ion 3.7V 3600mAh 13.32Wh
Battery Type Microphone : Li-ion 3.7V 400mAh 1.48Wh
Frequency Response : 50-20KHZ
Dimension: 149 x 154 x 330mm
Net Weight : 1.33kg

Safety Instructions :

- Avoid using it in rain, near water, near fire and flammable substances.
- Store it in a safe place to prevent dust and dirt affecting the product.
- Disconnect the main plugs from the outlet before cleaning the unit. Only use soft cloth, no harsh abrasives or chemicals to clean, as it will damage the surface finishing.

PORTRONICS

www.portronics.com

For Support

Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(Working Hours : Monday - Saturday, 10:00am - 6:00pm)

E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste