




## BEEM 560

Smart Led Projector

User Manual



### INTRODUCTION


Thank you for purchasing the Beem 560 Smart LED Projector. This user manual provides step-by-step guidance on setup, operation, and maintenance to help you achieve the best performance and extend the life of your projector. Please read the instructions thoroughly before using the device to ensure safe and optimal operation.

### SAFETY PRECAUTIONS

- Ensure there are no obstacles within 30 cm of the projector's air inlet and outlet during use.
- Provide adequate ventilation to prevent heat buildup inside the projector.
- Blocked airflow may cause overheating and abnormal functioning of the projector. (Refer to the diagram for correct setup.)

### Dust Maintenance

- After using the dust removal window, always close it properly. Leaving it open may cause serious damage to the projector.
- Regularly clean the air inlet dust screen to prevent dust accumulation, which can block airflow and damage the device.
- Use soft brushes, a vacuum cleaner, or similar tools for cleaning.



### CAUTIONS AND WARNINGS

For the best viewing experience, it is recommended to use this product in a dark room.

1. Do not install the projector in areas exposed to direct air conditioning, moisture, or high temperatures, as this may cause malfunction.
2. Ensure proper ventilation at all times. Blocked airflow can lead to overheating or failure.
3. Never insert clips, paper, metal objects, or any foreign items into the projector. If something accidentally falls inside, power off immediately and contact Portronics service personnel.
4. To prevent the risk of electrical damage, do not place liquids on or near the projector.
5. When transporting the projector, use soft protective materials and always cover the lens with the lens cap to avoid scratches or damage.
6. After use, the exhaust vent area may be hot. Avoid touching it directly with bare hands.
7. Never look directly into the projector lens while it is powered on, as this can cause serious eye injury.

### IMPORTANT NOTICES

#### Notice 1

Do not attempt to open the projector casing. Internal maintenance should only be carried out by trained professionals.


#### Notice 2

Warning: The internal parts of the projector may contain uninsulated high voltage and surface magnetic fields. Do not touch internal components, as this can result in serious electric shock.


#### Notice 3

To prevent fire or electric shock, never expose the projector to rain, moisture, or wet conditions under any circumstances.

### LIST OF ITEMS



### OVERVIEW



#### Tips


##### 1. Blurry image

- Go to **Settings** → **Lens** → **Autofocus Settings** on the homepage to adjust image clarity.
- You can also press the **Focus button** on the remote control to achieve the best clarity.

##### 2. Mounting Hole

- The projector features a **dual-use single mounting hole design**, making it compatible with standard camera tripods and **1/4-inch screw projector tripod stands**.

### REMOTE CONTROL




Note: The matching interface of Bluetooth remote control, Press "Voice input" button to bring up the matching guide.


### Bluetooth Remote Controller Pairing

To pair the remote controller with the projector:


1. Keep the remote controller close to the projector.
2. Press and hold both the **Left** and **Right** buttons simultaneously for **3 seconds**.
3. The remote will pair automatically.



### GETTING STARTED




Plug the power cable to the projector. Press power button to turn on the projector.




Use the manual focus by pressing the "Focus" button on the remote control.

**Tips:** Make sure the projector is horizontal to the projector screen.


### CLEANING METHOD



Get the screwdriver ready, unscrew the screws.




Clean the projector by the cotton swab.



Reinstall the bottom cover after cleaning.


### NETWORK SETTING

To connect the projector to Wi-Fi, go to **Settings** → **Network** → **Wi-Fi** → **Connect to Network** on the homepage, select your desired Wi-Fi network, and enter the password to establish the connection.




### BLUETOOTH SETTING

To connect a Bluetooth device, go to **Settings** → **Network** → **Bluetooth** on the homepage, select **Search for Bluetooth Device**, then choose your desired device from the list and click **Pair** to complete the connection.




### PICTURE SETTING

Go to **Settings** → **Picture** on the homepage to customize your viewing experience. Here you can adjust picture settings, switch between picture modes, and enable eye protection mode.




### SOUND SETTING

Go to **Settings** → **Sound** on the homepage to customize audio preferences. You can adjust sound balance, change sound modes, select the output device, and configure the output format for optimal sound quality.




### LENS SETTING

Go to **Settings** → **Lens** on the homepage to adjust projection settings. Here you can set the projection direction, enable autofocus, use keystone correction, and apply digital zoom for the best viewing experience.




### DEVICE PREFERENCE

Go to **Settings** → **Device Preferences** on the homepage to customize your projector. Here you can change the language, set date and time, choose keyboard options, configure screen saver and sleep timer, check device information, reset or restart the projector, enable Whale OS cast, adjust energy saver settings, and set the menu timer.




### WHALE OS CAST

To use screen casting, first connect your phone and the projector to the same Wi-Fi network. Then go to **Settings** → **Device Preferences** → **Whale OS Cast** → **TV Casting** and follow the on-screen instructions to download the TV Casting app. After installation, search for the projector device on your phone and select it to share your screen.




### APP SETTING

Go to **Settings** → **App Setting** on the homepage to manage applications. Here you can check recently opened apps, view all installed applications, and manage app permissions.




### VOICE SERVICE

Go to **Settings** → **Voice Service** on the homepage to adjust voice options. Here you can change the language and modify the tone of the intelligent speech feature.




### SOFTWARE UPDATE

Go to **Settings** → **Software Update** on the homepage to check for the latest updates, install new software, and view the current software version of your projector.





### FILE MANAGEMENT

Insert a U disk into the projector, then click the **File** icon on the homepage to access its contents. Supported files include videos, audio, pictures, and more.



### BLUETOOTH SPEAKER

To use the projector as a Bluetooth speaker, click the **Bluetooth Speaker** icon on the desktop to enter speaker mode. On your mobile phone, search for the projector's name, then pair and connect. You can select **Turn Off Screen** to switch off the display while keeping audio active, and press the **Back** button to exit this mode.



[www.portronics.com](http://www.portronics.com)

For Support

Visit : [www.portronics.com](http://www.portronics.com)

E-mail : [help@portronics.com](mailto:help@portronics.com)

Contact No.: +91 9555245245

(Working Hours: Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management

E-info@3rrecycler.com

For E-Waste & ROHS compliance refer to [www.portronics.com/ewaste](http://www.portronics.com/ewaste)