




CLIPCOOL

Powerful & Adjustable 360° Rotation Fan



User Manual

Product Parameters

Product Name	:	ClipCool
Product Model	:	POR 3050
Product Size	:	168x222x104mm
Rated Voltage	:	4.2V
Rated Power	:	5W

Fan Operation

Turning On the Fan:

Press the fan key switch once to turn on the fan.
The white indicator light will turn on simultaneously.

The fan speed can be adjusted in four levels:


First press: Low speed (natural wind mode).

Second press: Medium speed.

Third press: High speed.

Fourth press: Maximum speed.

Fifth press: Turns off the fan, and the indicator light will also turn off.



Light Operation

Turning On the Light:

Press the light key switch to turn on the light without activating the indicator light.

The light has two brightness levels:

First press: Low brightness.

Second press: High brightness.

Third press: Turns off the light.

Charging Instructions

Low Battery Warning:

When the battery is low, the indicator light will flash to indicate that charging is required.

Charging the Device:

While charging, the white indicator light will flash slowly.

Once fully charged, the indicator light will remain steady, indicating that you can unplug the power source



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste