



CONCH Z

Type C Wired Earphone

User Manual



Power On / Off

- Power On: Plug the Type-C connector into your phone.
- Power Off: Unplug the Type-C connector from your phone.

ANC & Transparency Modes

- ANC On: Press the ANC button - White light ON - Voice prompt.
- ANC Off: Press the ANC button again - White light OFF -Voice prompt.
- Transparency Mode: Press the ANC button - White light ON - Voice prompt.

Calls

- Incoming Call: Ring sound.
- Pick Up: Short press the MFB (▶||) button.
- Hang Up: Long press the MFB (▶||) button.
- Reject Call: Long press the MFB (▶||) button.

Music Controls

- Play / Pause: Short press the MFB (▶||) button.
- Next Track: Long press the '-' button.
- Previous Track: Long press the '+' button.
- Volume +: Short press the '+' button.
- Volume -: Short press the '-' button.

EQ Modes

- Switch EQ: Double-press the MFB (▶||) button - Voice prompt.
- There are 5 different EQ sound modes.

Note for Android Users:

If your device is not detecting the product, please enable OTG from your phone settings.

(Usually found under Settings > Additional Settings > OTG or Settings > Connected Devices.)

Note for iPhone Users:

If the product is not working, please allow wired accessory access:

Settings Privacy & Security Wired Accessories

Enable permission when prompted.



www.portronics.com
For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-waste Management

Email - info@3rrecycler.com

For E-waste & ROHS compliance refer to
<http://www.portronics.com/ewaste.html>