

FREEDOM 4E

15W Wireless Charging With
Digital Alarm Clock



User Manual

PACKAGE CONTENTS:

- Wireless Charger 1 N
- Type C to Type C Charging Cable (1M) 1 N
- User Manual 1 N

SPECIFICATION:

Input	9V/3A, 5V/3A
Wireless Output	5W/7.5W/10W/15W
Transmission distance	1-8 mm
Conversion	≥ 75%
Material	ABS + Fabric
Dimensions	155*129*71 MM
Weight	310.6g
Type-C to Type-C Cable Length	1m

Wireless Charging Standard:
Qi Compatible(supports all Qi-enabled devices)

PARTS DESCRIPTION:

(Refer to product illustration for labeled parts including power button, "M" button, "+" and "-" buttons, wireless charging pad, LED display.)



OPERATION:

1. Setting the Time

1. Press and hold the "M" button for 2 seconds to enter 12/24-hour format selection.
2. Use the "+" or "-" buttons to toggle between formats.
3. Press "M" to confirm and proceed to set the hour and minutes.
4. Once time is set, press "M" again to exit.
5. To switch between Celsius (°C) and Fahrenheit (°F), long press "+" during time display mode.

2. Setting the Date

- In time display mode, press "M" once to show the date.
- Long press "M" to enter year, month, and day setting.
- Use "+" or "-" to adjust each value.

3. Alarm & Snooze Function

1. In time display mode, press "M" once to display the date, then again to access the alarm settings.
2. Use "+" or "-" to activate/deactivate Alarm 1 (ON1/--A1) and Alarm 2 (ON2/--A2).
3. Long press "M" in alarm mode to set the alarm time.
4. Use "+" or "-" to adjust hours and minutes.
5. The alarm rings for 60 seconds, snoozes for 5 minutes, and repeats up to 5 times.
6. During ringing, press "+", "-", or "M"

4. Adjusting Display Brightness

- Press "-" in time display mode to switch between brightness levels: Strong - Medium - Weak - Off

5. Display Mode Settings (DP Modes)

- Press "+" in time display mode to cycle through DP modes:
- DP-1: Alternates between time/temperature and date every 10s and 2s respectively.
- DP-2: Displays only time and temperature.
- DP-3: Displays only date (year/month/day).
- Press "M" to confirm and exit.

6. Power On/Off

- Short press the Power button to turn the digital display on or off.
- Note: The screen will revert to time display after 5 seconds of inactivity.

SAFETY INSTRUCTIONS:

1. Keep away from water or moisture.
2. Turn off power before cleaning.
3. Recommended operating temperature: 1°C to 45°C.
4. Use only with compatible devices to prevent overheating.
5. Ensure proper alignment of phone on wireless pad to avoid charging issues.
6. Remove thick, metal, or magnetic cases (over 5mm) for optimal charging.
7. Avoid using the phone while charging to prevent heat build-up.
8. Remove the device from the charging pad once fully charged.
9. Do not leave the product unattended during charging.

CHILD SAFETY:

This device may be used by children aged 8 and above, and by individuals with reduced physical, sensory, or mental capabilities, only under supervision or instruction on safe usage. Children should not play with the device. Cleaning and maintenance should not be performed by children without supervision.

WEEE DISPOSAL INFORMATION:

This product is marked with the wheelee bin symbol, indicating that it should not be disposed of with household waste. Please take it to a designated WEEE collection point for proper recycling. Contact your local authority for collection details.