

# **IRON BEATS IV**With Wireless Karaoke Mic



Please carefully read the operating instruction before using our product

User Manual

# PACKAGE CONTAINS

- 1. Speaker 1N
- 2. Power Adapter 1N
- 3. Wireless Mic 1N
- 4. Remote 1N
- 5. Documentation 1 N

## **POWER AND CHARGING**

- 1. DC FUSE: A protective fuse for the machine's power supply, rated at F10A/250V.
- 2. DC 9V IN : Connect the external power adapter here. Always use the original adapter provided.
- 3. CHARGING (Indicator Lamp): Lights up when the adapter is connected and the battery is charging.
- 4. FULL (Charge Indicator Lamp): Lights up when the battery is fully charged.

#### WIRELESS MICROPHONE AND ANTENNA

1. WIRELESS MIC ANT: This is the built-in antenna for the wireless microphone. Always position it vertically for the best signal reception.

# **USB AND TF CARD FUNCTIONS**

- 1. **USB Interface**: Insert a USB drive with MP3 files to use the built-in MP3 playback function.
- 2. **TF Card**: Insert a TF card with MP3 files for playback.

# PLAYBACK CONTROLS

- 1. Stop Key ▶: Press to stop the current playback. It's recommended to press this button before changing the USB drive.
- 2. MP3/LINE MODE: Switch between external audio input and the built-in MP3 playback system.
- 3. **Key** ★ : Select the previous song during playback.
- 4. Key ▶ : Select the next song during playback.
- 5. **REPEAT**: Press to repeat either a single song or all songs.

#### **OPERATION OF FM RECEIVING FUNCTION**

- 1. SCAN key-pressing: press the key and the radio will scan the local radio station and save it automatically.
- 2. CH+ key-pressing: press the key and the radio will read the saved radio station and select the next one in ascending order.

**Note**: MODE key is used to switch radio status in order to use radio keypressing function; if the receiving frequency needs inputting manually, press the numbers on remote control directly to input the frequency of radio station.

# HANDHELD / HEADSET MICROPHONE



- **1-Display:**It shows the channel,frequency, signal, etc.
- **2-Power switch:** Single press to switch on/off the microphone
- **3-Battery cover:** Unscrew this cover to access the battery holder. Use two batteries type LR6-AA preferably alkaline. When inserting the batteries, make sure that the polarity is correct

# **REMOTE CONTROL**



- **1-MUTE:**One key sound mute function button
- 2- MODE: Switch MODE
- 3-REC: One touch recording function button
- **4-REC PLAY:** Record the recording playback function
- **5-FUNCTIONAL AREA:** 1.VOL+/-:1.USB/SD/M P3 player module VOL controls 2.CH+/CH-:Radio up and down channel selection
- 3. ►IIstart and pause playback
- 6-C>REPEAT: Loop function key
- **7-EQ:** Allows you to select between different equalizations
- 8-SELECT KEYS: select the song by number

# PANEL FUNCTION AND OPERATION



**1-DELAY**: Song delay function debugging

2-ECHO:Song echo function

**3-BASS**:Bass function debugging

4-TREBLE: Bass function debugging

**5-LAMP EFFECT**: Product display light effect

6-REC: Product recording function

**7-MODE**:Toggle play function

**8-MIC VOL**:Microphone volume adjustment

**9-VOLUME**:Product volume adjustment

10-1◀◀:Play the previous song

**11-**►II :Product play/pause adjustment

**12-** ▶►I:Play the next song

## **SPECIFICATION**

Product Dimension	300 x 300x 640 mm
Woofer Size/spec	Double 6.5 inch
Function List	USB/ TF ,AUX In, Wired Mic Input,
	LED Display,Bluetooth, Remote Control,
	Recording, LED Colour Light Switch,Microphone
	priority,Replay,Repeat,Volume ,FM Raido,TWS
Playing format	Мр3
Microphone input	Wired mic input x 1
Bluetooth Range	Bluetooth 10m
Bluetooth version	5.3
Frequency	50Hz-16KHz
FM Antenna	Internal FM Cable
Connectivity port	Aux-in, MIC-in,USB-in
USB player format	Мр3
LED Lighting	RGB Colour
LED Display	LED Display
DC-in	BIS certificate adapter-9V2A
Battery	7.4V/3600Ah lithium battery
Accessories	1. User Manual x 1
	2. Remote Control x 1
	3. BIS 9V2A Adapter x 1 1.2m
	4. Wireless mic x 1
Net Weight	8.1Kg
Gross Weight	10.1Kg



#### www.portronics.com

For Support

Visit: www.portronics.com

Email: help@portronics.com

Contact No.: +91 9555245245, 011-42413131

(Working Hrs.: Monday - Saturday 10:00am - 6:00pm)



E-Waste Management E: info@3rrecycler.com For E-Waste & ROHS compliance refer to www.portronics.com/ewaste