

PORTRONICS

LOCKSY

2-in-1 Sealer & Cutter



User Manual


Package Contents

Locksy 1N
Charging Cable 1N
User Manual 1N

Safety Measures

1. If the machine overheats, stop use for at least **2 minutes**.
2. Do not insert hard or sharp objects into the heating element.
3. Keep the device **clean and dry**. If damp, wipe with a dry cloth.
4. Keep out of reach of children.
5. If unused for long periods, turn off the device and recharge it every **3 months** before storage in a cool, shaded place.

Product Illustration



Product Parameter

Charging Voltage : DC 5V-1A
Battery Capacity : 400mAh
Size : 12 x 3.5 x 4.1 cm
Charging Port Type : Type-C
Charging Time : About 3 Hours

Charging Instructions

- While charging: **Red light ON** (steady).
- Fully charged: **Red light OFF**.
- In use: **Blue light ON** (steady).

Tips:

1. Fully charge before first use.
2. Only use the provided cable to charge this device.


How To Use

For Sealing:

1. Press the Power Button – the blue light will turn on.
2. Press and hold the Sealing Button, clamp the bag opening, and slide evenly.
3. Seal both the start and end points for a secure closure.

For Opening:

1. Insert the bag into the opening slot of the machine.
2. Press and hold the Opening Button and slide it to the right to open the bag.



PORTRONICS

www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management
E: info@3recycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste