



☑ iOS ☑ Android

HOW TO USE

Switch on and off: Dial the power key up to turn on the power; dial the power key down to turn off the power

Wireless pairing: The indicator light flashes quickly for 4s to enter the pairing state, the pairing status indicator flashes, use the mobile phone to search for "Selfie" to match, and the indicator light will turn off after the pairing is successful.

Take photos: When the selfie stick device is connected to the mobile phone, press the photo button and the indicator will blinks.

Unpaired: After startup, if left unpaired and without any operation for 5 minutes, the selfie stick will automatically power down. To resume, switch it on again.

Paired: When connected to the phone, the indicator light turns off after pairing. It enters sleep mode if inactive for 10 minutes. Simply press any button to wake it up.

Automatic connection: Upon powering on or waking up from sleep, the selfie stick will automatically reconnect to the previously paired phone if it was connected before.

KEY FUNCTION

Power on

light out

Use after taking out the Selfie stick and connecting the phone.



Photo key

click:

Take pictures/video

HOW TO CLIP PHONE

TAKE OUT THE REMOTE

Use one end of the phone to push the clip upwards.





HOW TO OPEN A TRIPOD

tripod mode.

Pull the rod out first, then slide it up to remove. Open the handle outwards to turn it into









EXTENDABLE

The stainless steel poll can be extended up to 1160mm.



ADJUST VARIOUS ANGLES

Adjust various angles to shoot.









HOW TO USE FILL LIGHT

Press and hold the power button for 2 seconds to turn on the light, then press to dim.

Light transformation mode : White light: Soft , Bright ;

Warm light: Soft , Bright ; Natural light: Soft, Bright.

Press and hold the power button at any time to tum off the light and remember,

_____,

When charging, the red light is on, and the light is off when it is full.

(Batteries must not be exposed to sunlight, fire, or

Main Material: ABS+Stainless Steel

similar excessive heat)

SPECIFICATION

Folded Length: 210mm

Product Weight: 220g

Extended Length: 1160mm

Product Size: 210x59x38mm

Battery : CR1632(replaceable)



www.portronics.com

Visit: www.portronics.com Email: help@portronics.com Contact No.: +91 9555245245, 011-42413131 (Working Hrs.: Monday - Saturday 10:00am - 6:00pm)

E-waste Management

Email - info@3rrecycler.com For E-waste & ROHS compliance refer to

http://www.portronics.com/ewaste.html

User Manual