




LUXCELL WIRELESS MINI

10000mAh Power Bank



Thank-you for choosing Portronics.
We're happy to help you understand how to use
this product. Read on!


User Manual

Package Contents :

1. Power Bank
2. Charging Cable
3. User Manual

Luxcell Wireless Mini

1. LED Indicator
2. USB Output
3. Type-C Input
4. Wakeup Button
5. Magnetic Wireless Charging Area



Charging Your Devices

A button is located on the side of the Power Bank.

- When the button is pressed, the LED indicators display the remaining battery capacity, and it also powers on the Power Bank.
- The LED indicators turn off by double pressing the power button.

When charging a USB device, please refer to the guide below to understand the LED Indications:

| Percentage | LED 1 | LED 2 | LED 3 | LED 4 |
|------------|-------|-------|-------|-------|
| 76 - 100% | On | On | On | On |
| 51 - 75% | On | On | On | Off |
| 26 - 50% | On | On | Off | Off |
| 1 - 25% | On | Off | Off | Off |
| 0% | Off | Off | Off | Off |

To charge your mobile phone with this Powerbank, simply connect the charging cable provided.

Charging the Power Bank

Repeat the steps mentioned above to navigate through the powerbank. When charging your Powerbank, please refer to the guide below to understand the LED Indications.

| Percentage | LED 1 | LED 2 | LED 3 | LED 4 |
|------------|----------|----------|----------|----------|
| 0 - 25% | Blinking | Off | Off | Off |
| 26 - 50% | On | Blinking | Off | Off |
| 51 - 75% | On | On | Blinking | Off |
| 76 - 100% | On | On | On | On |
| Abnormal | Blinking | Blinking | Blinking | Blinking |

To charge your powerbank, connect the Type C port located on the Power Bank to the USB-A port on a computer or USB charger, using the Charging cable provided.

DOS and DON'Ts

- Make sure the Power Bank is fully charged prior to use.
- Use a cable suitable for your device when charging it from the Power Bank.
- When charging the Power Bank, it is recommended that you use the included charging cable.
- Recharge the Power Bank as soon as possible to avoid shortening the battery life.
- The battery should be charged at least every three months to avoid shortening the battery life.
- Do not wash the Power Bank with corrosive cleaner.

Technical Specifications :

Capacity : 10000mAh
 Input (Type-C) : DC 5V=3A / 9V=2A
 Output (Type-C) : DC 5V=3A / 9V=2.22A / 12V=1.67A
 Output (USB) : DC 5V=3A / 9V=2A / 10V=2.25A / 12V=1.5A(22.5W MAX)
 Magsafe Output : 5W/7.5W/10W/15W
 Max Output(Type-C + USB-A) : DC 5V=3A



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 955245245 , 011-42413131

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-waste Management

Email - info@3recycler.com

For E-waste & ROHS compliance refer to
<http://www.portronics.com/ewaste.html>