E Portronics



Mport 4A

4Ports USB Hub

USER MANUAL

Introduction


Plug and play

Thanks for choosing our Mport 4A by portronics. This device will help you to connect all your favorite devices like printer, U Disk, keyboard, mouse, hardisk with your PC/Laptop.

Product Features : Package Contents : USB Hub Windows, Mac OS, Chrome OS, Linux supported User manual

USB3.0 USB3.0 USB3.0 -Micro USB3 **.**... USB 3.0 AM

Connection Method



Specifications :

Input

Output

x 1

x 1

: USB3.0 X 1

: USB 3.0 x 4, Upto 5Gbps data transmission speed, backward compatibility with USB 2.0/1.1 HDMI

Input Voltage : Micro USB DC 5V

Cable Length : 50CM

Housing Material : PC + ABS

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. Water and Moisture - The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.

2. Heat - The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.

3. Cleaning - The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.

4. Objects and Liquid Entry - Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.

5. Attachments - Do not use attachments not recommended by the product manufacturer.

6. Overloading - Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

7. Damage Requiring Service - The unit should be serviced by gualified service nersonnel when:

A. the power supply cable or plug has been damaged.B. objects have fallen into or liquid has been spilled into the enclosure. C. the unit has been exposed to rain.D. the unit has been dropped or the enclosure damaged.E. the unit exhibits a marked change in performance or does not operate normally.

8. Servicing - The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to gualified service personnel.

NOTE: Any damage caused by physical impact, Water/liquid, fire etc caused by customer or nature shall not be covered under warranty. Only product design, feature and functionality related faults will be considered.



Have a query? We are happ<u>y to help :</u>

For Consumer Complaint : Visit : www.portronics.com Email : help@portronics.com Customer Care Exceutive Number +91 9555245245, 011-42413131 (Working Hrs. : Monday - Saturday 10:00am - 6:00pm)

0

Follow Us On :

Portronics portronicsdigital portronics.india portronics.india/



Email - info@3rrecvcler.com

For E-waste & ROHS compliance refer to http://www.portropics.com/ewaste.html