


NIXO

UV Electric Mosquito Killer Lamp



User Manual

Nixo

This insect killer effectively attracts and eliminates flying insects using UV light and a high-voltage grid. Its modern, chemical-free design is safe, efficient, and ideal for homes, offices, and other indoor spaces.

Package Contains

Nixo 1 N, USB Wire 1 N,
Brush 1 N, User Manual 1 N

Technical Specifications

- Input port – Type c
- Input voltage/current – 5V/2A
- Input power – 7W
- Electric Shock Voltage – 800V to 1000V
- Fan – Yes
- Light – UV LED
- Material – ABS plastic

Product Overview

- Buttons
- Hanging option
- Red LED
- High voltage grid
- UV light
- Type c port
- Fan
- Collecting tray



How to Use?

WORKING: The device can be operated in 3 working modes, electric shock mode, silent mode & combined mode.

1. Electric Shock Mode:

Press the switch with the lightning symbol (⚡).
The UV LED lamp and the high voltage grid will turn ON.
Press it again to turn OFF.

2. Silent Mode:

Press the switch with the fan symbol (🌀). The UV LED lamp and the fan will turn ON. Press it again to turn OFF.

3. Combined Mode:

Press both switches simultaneously (⚡🌀).
The UV LED lamp, the high-voltage grid, and the fan will all operate at the same time. To turn the unit OFF completely, press both switches.
To turn OFF an individual mode, press its corresponding switch.

WHEN THE RED LED INSIDE THE DEVICE LITS, IT DENOTES THAT THE HIGH VOLTAGE GRID IS TURNED ON.

WASTE REMOVAL: The dead insects are collected in the removable collection tray for easy cleaning.

Safety Instructions

1. This appliance is for indoor use only. Do not use it in damp areas or near flammable materials, explosive substance, or combustible materials.
2. Keep the appliance out of the reach of children. Children should not use or play with the appliance.
3. Do not touch the high-voltage grid or insert fingers or metal objects into the appliance while it is operating.
4. Always unplug the appliance before cleaning or maintenance. Do not wash the appliance with water or expose it to rain.
5. Do not disassemble or repair the appliance yourself. Never use the appliance with a damaged wire.



E-Waste Management
E: info@3rrecycler.com
For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste

www.portronics.com

For Support

Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(Working Hours. : Monday – Saturday 10:00am – 6:00pm)