

# POWER BANK SAFETY INSTRUCTIONS



## STORAGE GUIDELINES

- **Store Safely:** Keep the power bank in a cool, dry place. Avoid direct sunlight, excessive heat (such as inside a parked car), or freezing temperatures.
- **Partial Charge for Long-Term Storage:** If unused for an extended period, store the power bank at 50–60% charge.
- **Avoid Moisture:** Keep away from water, rain, or humid environments to prevent corrosion or short circuits.



## HANDLING & GENERAL SAFETY

- **Inspect Regularly:** Discontinue use immediately if you notice swelling, cracks, leakage, or exposed wires.
- **Avoid Drops & Impact:** Do not drop, crush, bend, or apply pressure to the power bank.
- **If Dropped:** Immediately move the power bank to an open, well-ventilated area. Inspect for damage and allow it to rest for some time before reuse. If any abnormality is observed, stop using it.
- **Keep Away from Metal Objects:** Avoid contact with coins, keys, or other metal items.
- **Prevent Overheating:** If the power bank becomes unusually hot, unplug it and allow it to cool completely.
- **Do Not Disassemble:** Never open, modify, or attempt to repair the power bank yourself.
- **Do Not Keep in Pockets During Use:** Always hold the power bank in your hand or place it on a flat, open surface while operating.

# POWER BANK SAFETY INSTRUCTIONS



## CHARGING INSTRUCTIONS

- Use Certified Accessories: Use only the supplied cable or certified high-quality charging accessories.
- Avoid Overcharging: Unplug the power bank once it is fully charged.
- Do Not Charge Overnight: Avoid leaving the power bank plugged in overnight or unattended.
- No Simultaneous Charging & Discharging: Do not charge the power bank while it is charging other devices.
- Charge Safely: Always place the power bank on a flat, non-flammable surface while charging.



## UNSAFE USAGE CONDITIONS

- Do not place the power bank on beds, cushions, sofas, or under pillows.
- Do not store in pockets or bags containing metal objects.
- Keep away from heaters, radiators, or open flames.
- Do not leave on car dashboards or in direct sunlight.



## FIRE SAFETY

- In Case of Fire: Use a Class D fire extinguisher or sand.

# POWER BANK SAFETY INSTRUCTIONS



## LOAD & PERFORMANCE SAFETY

- Avoid Overloading: Connect only devices within the rated output capacity.
- Single Device Recommended: Avoid charging multiple phones simultaneously.



## AIR TRAVEL SAFETY

- Carry power banks only in hand baggage.
- Do not use or charge devices with the power bank during flights.



## DISPOSAL & RECYCLING

- Dispose of the power bank responsibly at authorized electronic waste (e-waste) recycling centers only.



## HANDLING A SWOLLEN POWER BANK

- If the power bank shows signs of swelling, stop using it immediately. Unplug it carefully and place it on a non-flammable surface, away from people, pets, and flammable materials. Do not puncture, crush, or open the device. Allow it to cool completely and dispose of it at an authorized electronic waste recycling center in accordance with local regulations. Contact the manufacturer for further guidance.