



Product Overview

PingU is a compact and modern USB wireless doorbell designed for convenient everyday use at homes, offices, shops, and apartments. With its wire-free setup and USB-powered receiver, PingU offers a simple plug-and-play experience without complicated installation.

Specifications

Product Name : Ping U USB Wireless Doorbell  
Receiver Power Input : USB Plug ~ 5V  
Transmitter Battery : CR2032 3V  
Material : ABS  
Ringtones : 38 Musical Chimes  
Volume Levels : 4 Levels (including Mute Mode)  
Wireless Range : Up to 200 ft (Open Area)  
Transmitter Protection : IP44 Rated  
Receiver Indicator : LED Flash Light

Package Contents

- USB Wireless Receiver 1 N
- Wireless Transmitter 1 N
- Adhesive Tape 1 N
- User Manual 1 N

Product Features:

A. Receiver

The receiver plugs directly into a 5V USB power source such as:

- Mobile charger adapter
- USB-A port
- Power extension with USB output

Receiver Controls

- Music Button – Change Musical Chimes
- Volume Button – Adjust sound level

B. Transmitter

The transmitter is the outdoor button used to ring the bell wirelessly that runs on CR2032 3V cell.

How to Use

Step 1: Power the Receiver

- Plug the receiver into a 5V USB power supply.
- The receiver will power on automatically.
- Note: Use a standard USB charger adapter for stable performance.

Step 2: Place the Transmitter

Attach the transmitter to the desired surface using the adhesive tape.

Step 3: Pairing

- The transmitter and receiver are pre-paired before delivery.
- Simply press the transmitter button to ring the bell.

Music Selection

- Press the Music Button to browse through available melodies.
- Stop pressing once your preferred ringtone is selected.

Volume Adjustment

- Press the Volume Button to change the sound level.
- The doorbell supports 3 volume levels.

Troubleshooting

- Doorbell not ringing – Check transmitter battery installation
- Weak signal – Reduce distance or remove metal obstructions

- No power to receiver – Verify USB power supply is working
- Low sound – Increase volume level

Care & Maintenance

- Keep the product clean and dry.
- Do not disassemble the device unnecessarily.
- Store in a cool and dry place when not in use.



**PORTRONICS**



E-Waste Management  
E-info@3mrecycler.com  
For E-Waste & RoHS compliance  
refer to www.portronics.com/ewaste

**www.portronics.com**  
For Support  
Visit : [www.portronics.com](http://www.portronics.com)  
Email : [help@portronics.com](mailto:help@portronics.com)  
Contact No. : +91 9555245245  
(Working Hours: Monday -  
Saturday 10:00am - 6:00pm)