

POWER PLUS II

Power Up your Home Entertainment



Thank-you for choosing Portronics. We're happy to help you understand how to use this product. Read on!

User Manual

PACKAGE CONTENTS

1. Power plus II- 1 N

- 2. Charging Cable -1 N
- 3. User Manual

QUICK & EASY INSTALLATION

- Unplug the Power Adapter from the WiFi Router
- Connect the Power Adapter to Input Port of Power Plus II
- · Connect the Output of Power Plus II to Your WiFi Router
- Red Led indicator getting on while charging and ouput

TECHNICAL SPECIFICATIONS

Input: 12v3A Output: 12v3A

Battery Backup: upto 4 hour (Efficiency is depending on your

wifi power Amp)

LED Indicators : Red light (charging and gives output)

Green light (NO charging but gives output)

Toggle Switch : On/off Power supply (For charging kindly switch on)

Battery Type : Li-ion

Overcurrent Protection: Protected

Short Circuit Protection: Protected

HANDLING

- Inspect for Damage: Regularly check for signs of wear, such as a swollen battery, cracked casing, or exposed wires. If you notice any damage, stop using it immediately and dispose of it safely
- Don't Drop or Crush: Physical damage can rupture the battery, leading to leaks or even a fire hazard.
- Avoid Overheating: If the power plus II feels unusually hot during use or charging, unplug it and let it cool down before using it again.
 Persistent overheating is a sign of a problem
- Don't Disassemble: Never attempt to open or repair a Power plus II yourself. Internal components like lithium batteries can be dangerous if mishandled
- Charge in a Safe Environment: Place the power plus II on a flat, non-flammable surface while charging. Avoid charging it on beds, sofas, or near flammable materials.
- Avoid Moisture : Keep it away from water or humid environments to prevent short circuits or corrosion

DISPOSAL

Proper Recycling: When your Power plus II reaches the end of its life, don't throw it in the trash. Take it to an electronics recycling center, as lithium batteries can be hazardous if improperly disposed of..

HANDLING A SWOLLEN POWER PLUS II

If your Power plus II swells, stop using it immediately and unplug it carefully, placing it on a non-flammable surface away from flammable items, people, and pets to avoid risks like leaks or explosions. Do not puncture or open it; instead, let it cool down and dispose of it at an electronics recycling center per local rules-never in regular trash. Contact the manufacturer for further advices.

IMPORTANT NOTE

The company will not be responsible for any damages injury, or malfunction resulting from improper usage, mishandling, or failure to follow the manufacturer's instructions





For E-waste & ROHS compliance refer to http://www.portronics.com/ewaste.html

www.portronics.com

For Support Visit : www.portronics.com

Email: help@portronics.com Contact No.: +91 9555245245

(Working Hrs.: Monday - Saturday 10:00am - 6:00pm)