



RAY X | Rechargeable LED Lamp




User Manual

Product Overview

Portronics Ray X is a rechargeable LED Lamp designed for daily lighting, power cuts, bedside use, shops, travel, and emergency backup. It comes with a rotary switch for easy brightness control and a bottom hanging hook for convenient placement.

Product Description

1. LED Lamp
 2. Rotary Switch
 3. Type C Charging Port
 4. Charging Indicator Light
- Red Light: Charging
 - Green Light: Fully Charged
 - 5. Bottom Hanging Hook



Specifications

Product Type: Rechargeable LED Lamp
Battery: 2x1500mAh Built-in Battery
Charging Time: 5-6 Hours
Lighting Source: 24 PCS SMD LED
Backup Time: High Brightness: 1-2 Hours, Low Brightness: Up to 10 Hours

How to Use

- Before first use, fully charge the Portronics Ray X.
- Turn the rotary switch clockwise to switch on the Lamp.
- Rotate the switch further to increase brightness.
- Rotate the switch back to reduce brightness or turn off the Lamp.
- Place it on a flat surface or use the bottom hook to hang it wherever needed.

How to Charge

- Connect the provided charging cable to the type-c port.
- Plug the other end into a USB power source such as an adapter, power bank.
- The charging indicator will glow red while charging.
- Once fully charged, the indicator will turn green.
- Remove the charging cable after full charge.

Important Instructions

- Charge the Lamp fully before first use.
- Recharge the battery every 3 months, even if the product is not in use.
- Do not immerse the light in water.
- Use only a suitable 5V USB power source for charging.
- Do not use the product if the charging cable or type-C is damaged.
- Children should use this product

only under adult supervision.

- Do not open, repair, or modify the product yourself.
- Do not cover the LED Lamp while it is in use.
- Avoid dropping or hitting the product.
- Keep the product away from flammable materials.
- If the product shows unusual heating, smell, or damage, stop using it immediately.

Troubleshooting

1. Issue : Lamp is not turning on
Solution : Charge the product fully and try again.

2. Issue : Light backup is low
Solution : Fully charge the light for 5-6 hours before use.

3. Issue : Charging indicator is not glowing

Solution : Check the Type-C cable, adapter, and power source.

4. Issue : Light is dim

Solution : Adjust the rotary switch or recharge the battery.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hours : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management

E-Info@wrecycle.com

For E-Waste & RoHS compliance refer to www.portronics.com/ewaste