





Spark X

Bluetooth Speaker




USER MANUAL

PACKING LIST



- 1 Play / Pause Button**
 - Press once to play or pause music.
 - In FM mode, press once to auto-scan FM channels.
 - Press and hold to switch to TWS/Bluetooth mode.
- 2 Next Track / Volume Up**
 - Press once to play the next track or FM channel.
 - Press and hold to increase the volume.
- 3 Previous Track / Volume Down**
 - Press once to play the previous track or FM channel.
 - Press and hold to decrease the volume.
- 4 Mode / Power Button**
 - Press once to change the operating mode: Bluetooth, TF Card, or FM Mode.
 - Press and hold to turn the device ON or OFF.



TECHNICAL SPECIFICATION

Total output power	: 5W
Frequency Range	: 80Hz - 18 KHz
Bluetooth Version	: 5.4
Total Battery Voltage and Capacity	: 3.7V 1500mAh
Battery Type	: Li-Ion 18650
Charging	: 5V (Type C)
Full Charge	: Red Indicator Off
Charging	: Red Indicator Blinking
Charging Time	: 2-3 Hours



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hours : Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste