





<p></p> <h1>STRINGS</h1> <p>16W Bluetooth Speaker</p>  <p>User Manual</p>	<h3>Package Contains</h3> <p>Portable Speaker 1 N Charging Cable 1 N Documentation 1 N</p> <h3>Wireless Charger Use: Plug In The Charger To Automatically Turn On</h3> <ul style="list-style-type: none">Ⓟ Long press power/short press light switch.Ⓜ Long press function switch BT/NS mode, short press pause/play, press three times to disable Bluetooth mode for the clock only.⌚ Short press the timing 15/30/60.⏮ Short press the next song, long press to add the volume.⏪ Short press the last song, long press to reduce the volume.⌚ Alarm clock setting.⌚ Clock Settings.	<h3>Technical Parameter</h3> <p>Wireless Charging Power: 15W Bluetooth Version: 5.3 Sound Output : 16W Wireless Frequency: 2.4GHZ-2.48GHZ Transmission Distance: 10 meters Frequency Sound Range: 50 HZ-20 KHZ Sigto Noise Ratio Of Whole Machine: Greater Than 75 db Built-in Lithium Battery: 3.7V/2500 mAh</p> <p>Please note: It requires at least a 30W adaptor to run all functions effectively when used together.</p> <p>The speaker runs on its internal battery, but wireless charging won't. It needs a minimum 25W adaptor to function.</p>	<h3>Power On</h3> <p>To turn on the device: Long press the Power button for 2 seconds. The default LED light will switch on automatically.</p> <h3>Wireless (Bluetooth) Mode</h3> <ul style="list-style-type: none">The speaker automatically starts in Wireless/Bluetooth mode when powered on.A blue light will blink, and you will hear a voice prompt indicating it's ready to pair <p>How to connect your phone:</p> <ol style="list-style-type: none">Open Bluetooth in your phone's settings.Turn on Bluetooth and search for new devices.Select "Strings" from the list. Once connected, you'll hear a prompt and the device name will appear
<h3>TWS Pairing (Two Speakers Together)</h3> <p>Place both speakers close to each other and switch both ON. On the first speaker, press and hold the "Timer" button until you hear the TWS pairing beep. Ensure the second speaker is in Bluetooth mode. The two speakers will automatically connect with each other and enter TWS mode.</p> <h3>Light Modes</h3> <ul style="list-style-type: none">Your speaker comes with 12 lighting effects.Double Click Light button to Turn off LED Lights.	<h3>TF Card / USB Drive Music</h3> <ul style="list-style-type: none">Insert a TF card or USB drive with music.The speaker will automatically start playing.Use Next and Previous Button to change volume or tracks. <h3>Clock Setting</h3> <ul style="list-style-type: none">Press the Time button to enter setting mode.Use Next and Previous Button to adjust hours and minutes.Press Time again to confirm. <h3>Alarm Setting</h3> <p>To Set an Alarm:</p> <ul style="list-style-type: none">Press the Alarm button to enter alarm setting mode.Use Next and Previous Button to set the hour and minute.Press the Alarm button again to select from 7 alarm tones.Press again to save. The alarm icon will appear.	<h3>During Alarm</h3> <ul style="list-style-type: none">Press any key to stop the alarm.If no key is pressed, it will stop automatically turn off after 1 minute. <h3>To Cancel Alarm</h3> <ul style="list-style-type: none">Long press the Alarm button until the alarm icon disappears. <h3>White Noise Mode</h3> <ul style="list-style-type: none">Press the M button to switch to White Noise mode.Use Next and Previous Button to choose your preferred sleep sound.	<p></p> <p>www.porttronics.com For Support Visit: www.porttronics.com Email: help@porttronics.com Contact No.: +91 9555245245</p> <p>(Working Hrs.: Monday - Saturday 10:00am - 6:00pm)</p> <p></p> <p>E-waste Management Email - info@3rrecycler.com For E-waste & ROHS compliance refer to http://www.porttronics.com/ewaste.html</p> <p>Wireless charging works only when you use an 18W (or higher) power adaptor. It will not function when the device is running on battery power.</p>