PORTRONICS



TWINS 33 PRO

Smart TWS Earbuds

User Manual

PACKAGE CONTENTS

1. Twins 33 Pro 1 N
2. User manual 1 N
3. Type C Charging Cable 1 N

POWER ON

- Take the buds out from the case, automatically turns ON.
- If the buds turned OFF after no connectivity, long press L/R bud for 3s to power ON

BLUETOOTH PAIRING

- Ensure both earbuds are ON and paired together.
- The main earbud enters pairing mode automatically.
- Turn ON your device, enable bluetooth and select the earbuds from the device list. LED alternates between white & orange while pairing.
- LED stops flashing after getting paired.

Touch Features Explained:

CALL FUNCTIONS

Single Tap L/R earbud to PICK CALL

Double tap L/R earbud to END CALL

Long press L/R earbud for 3s to REJECT CALL

Single Tap L/R earbud to:

Play/pause - music/video playback.

Double Tap R earbud to:-

To jump to the next song/video

Double Tap L earbud to:-

To jump to the previous song/video

Three Tap L/R earbud to:-

ANC On/Off/Transparent Mode Switching

3 Sec Long Press L/R earbud to:-

For Voice Assistant

AUTOMATIC RECONNECTION

- When powered ON, earbuds reconnect to the last connected device automatically.
- No LED flashing during reconnection.

RECONNECTION AFTER GOING OUT OF RANGE

- Automatically reconnects when back within range.
- If not, tap the bud to connect manually.

SHUTDOWN

- Earbuds auto power OFF if not connected within 5 minutes.
- Long press L/R bud for 5s to power OFF manually.

CHARGING

- Place the earbud in charging case. Orange LED on earbud stays for 10s then turns OFF, case white LED stays ON.
- The case shows no LED, when the earbuds is fully charged.
- White LED flashes in the the case when the battery is low.

LED INDICATOR GUIDE

Earbuds :

- **Pairing Mode :** White & orange LED flashing alternately
- **Connected :** No LED
- **Charging in Case :** Orange light turns OFF after 10s

Charging Case :

- **Charging Earbuds :** White light ON
- **Case Charging :** Orange light flashing
- **Case Fully Charged :** Orange light solid
- **Low Battery in Case :** White light flashing

BUDS RESET

- Manually turn OFF the buds by long pressing it for 5s and put it in charging for 10 minutes inside the case.
- Unpair/forget the buds from your device.
- Take out the buds from charging and wait a minute for the TWS pairing.
- After this pair the buds from your device.

SPECIFICATIONS

- Bluetooth Version: 6.0
- Wireless Range: 10 Metres
- Charging Input : 5V/1A
- Charging Time (Earbuds): 1.5 to 2 hours approx
- Charging Time (Case): 2 to 3 hours approx
- Battery Capacity (Earbuds): 3.7V/35 mAh each
- Battery Capacity (Case): 3.7V/400 mAh
- Charging Port: Type-C
- Microphone: Dual mic with ANC + ENC

PORTRONICS

www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)

E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste