



TWINS ONE

Smart TWS Earbuds

User Manual

WHAT'S IN THE BOX

- 1× pair of True Wireless Earbuds (L/R)
- 1× Type-C charging cable
- 1× User manual.

KEY FEATURES

- **Bluetooth Version** : 6.0
- **Touch controls**: play/pause, next/previous track, call answer/end/reject, voice assistant
- **Voice assistant**: Siri compatible
- **Charging port**: Type-C

TECHNICAL SPECIFICATIONS

- Bluetooth version: **6.0**
- Profiles supported: **A2DP, AVRCP, HSP, HFP**
- Audio frequency response: **20 Hz–20 kHz**
- Wireless range: **up to 10m**
- Earbud battery: **30 mAh(each)**
- Charging case battery: **240mAh**
- Charging time (case): **~1.5–2hours**

LED — CHARGING CASE

- While charging: **Red LED flashes**
- Fully charged: **Red LED stays solid**

POWER ON / OFF

- **Power ON**: Open the case and remove both earbuds. They turn on and pair with each other automatically.
- **Power OFF**: Put both earbuds back in the case and close the lid. They power off automatically.
- **Auto sleep**: If not connected to any device within 5 minutes, the earbuds power off.

PAIR & CONNECT TO YOUR PHONE

1. Open the case and take out both earbuds. Wait a few seconds for them to pair with each other (TWS).
2. On your phone, turn Bluetooth on search and select "Portronics Twins One."
3. Connection will complete in a moment. Next time, they reconnect automatically to the last paired device.

TOUCH CONTROLS

(MFB = Multi-Function Button on each earbud)

Music

- Play / Pause: Single-tap MFB on either earbud
- Next Track: Double-tap MFB on Right earbud
- Previous Track: Double-tap MFB on Left earbud

Calls

- Answer / Receive: Double-tap MFB on either earbud
- End Call: Double-tap MFB on either earbud
- Reject Call: Long-press MFB on either earbud for ~2 s

Voice Assistant

- Siri / Voice Assistant: Long-press MFB on either earbud for ~2 s
- Triple tap to toggle between Game and Music modes.

Note: Control behavior may vary slightly by phone model/OS.

SAFETY & CARE

1. Store in a dry, ventilated place. Keep away from oil, steam, moisture, and dust.
2. Do not clean with harsh solvents or chemicals.
3. For a stable connection, keep the phone within 10 m of the earbuds and minimize obstacles.
4. Do not disassemble the earbuds or accessories; doing so voids the warranty.
5. Use a standard, quality-certified charger to charge the case via the Type-C port.
6. Charge regularly to ensure sufficient power for normal use.

HELPFUL TIPS

- For best results, charge the case fully before first use.
- If one earbud isn't playing, place



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245, 011-42413131

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste