




VAYU 9.0

2-in-1 Cordless & Corded
Portable Tyre Inflator



USER MANUAL


INTRODUCTION

Thank you for choosing Vayu 9.0.
This portable and easy-to-use inflator is designed to help you accurately inflate car tires, bicycle tires, sports balls, and more—with precision and convenience.
Please read this manual carefully before use to ensure safe and proper operation.

SAFETY INSTRUCTIONS

1. Use the inflator only for its intended purposes.
2. Do not inflate objects beyond their recommended pressure limits.
3. Avoid operating the inflator in extreme temperatures or near flammable materials.
4. Keep out of reach of children to prevent accidental use
5. Allow the device to cool down after extended use to avoid overheating.
6. Fully charge the battery before using it for the first time.
7. Store the inflator in a cool, dry, and well-ventilated place.
8. Do not expose the device to water or other liquids.


PACKAGE CONTENTS



TECHNICAL SPECIFICATIONS

Product version	Corded and cordless
Product model	Vayu 9.0
Voltage	DC12V/11.1V
Battery Capacity	2000mAhx3

PHYSICAL SPECIFICATIONS




- 1 Digital Display Screen
- 2 Operation Buttons
- 3 LED Light
- 4 Air Hose Port
- 5 Type-C Charging Port
- 6 USB 5V 1A Output (cannot Be Used As A Charging Bank)
- 7 DC Port

5 BUILT-IN INFLATION MODES



PRESSURE PRE-SET


- To preset your desired tire pressure:
1. Press and hold the "Mode" button to switch the unit (e.g., PSI, BAR, KPA).
 2. Use the "+" or "-" buttons to adjust the pressure value.
 3. Once the desired value is set, wait a few seconds until the numbers stop flashing.
 4. Press the Start button to begin inflation.
 5. The inflator will automatically stop once it reaches the preset pressure.




OPERATION GUIDE

(1) Battery Powered Mode


Please ensure the device is fully charged before use.



(2) Cigarette Lighter Powered Mode



BATTERY DISPLAY



Digital display screen has three battery modes

First battery mark display: 100% > power > 70%

Second battery mark display: 70% > power > 40%

Third battery mark display: 40 > power > 10%

Third battery mark display flashing: Battery power less than 10% , Need to recharge.

TROUBLESHOOTING

Problem	Cause	Solution
Inflator does not start	Battery is low	Charge the battery fully
Inflation is slow	Nozzle not attached properly	Ensure a secure connection
Inflator stops suddenly	Overheating protection activated	Allow it to cool down



www.portronics.com

For Support

Visit : www.portronics.com

E-mail : help@portronics.com

Contact No.: +91 9555245245

(Working Hours: Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management
E: info@3recycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste