

Rechargeable Tyre Inflator



WARNING

- · Children should not be allowed to use this tyre inflator.
- Do not use this tyre inflator under sunlight or high heat conditions.
- · Avoid exposure to rain, liquid or moisture.
- · Switch off the tyre inflator after using.
- Please ensure to read all warnings and manual instructions before using the vacuum cleaner. Improper use may result in product damage or excess heat, for which the brand is not responsible.


ATTENTION

- To reduce the risk of electric shock, do not expose the tyre inflator to rain.
- Store it indoors and away from fire / high heat.
- To ensure long life of the tyre inflator, continuous inflation of more than 10 minutes is not recommended. If using for longer is unavoidable, please take intermittent breaks to allow the tyre inflator to cool down.

ACCESSORIES

USB charging cord

Cigarette lighter charging cable




6 Power Port

Type-C Charging port

Multifunction Nozzles

LAYOUT







You can press"+" or"-" to Short press "(')" to start

the target pressure, it will stop automatically.you can also stop inflating any time by pressing "()" Button.Make sure to turn off power switch after using

Press and hold for 3 seconds

Long press "M" three

seconds to change the

pressure unit

5 BUILD IN INFLATION MODELS












OPERATION GUIDE



Connect air hose to the Screw the air hose to the



Press "(י)" shortly to wake Press "M" button change up the screen or start 4 different mode" සෙරාගේය®"












PRESSURE PRE-SET

Long Press "M" Button change the pressure unit, Press: "+" or "-" increase or decrease the target pressure, after numbers stop flashing, Press " (')" button to start inflation, When it reach to the desired pressure, it will stop automatically.



BATTERY DISPLAY



Digital display screen has three battery modes

First battery mark display: 100% > power > 70% Second battery mark display: 70% > power > 40% Third battery mark display: 40 > power > 10% Third battery mark display flashing: Battery power less than 10%, Need to recharge.



www.portronics.com

For Support

Visit: www.portronics.com

E-mail: help@portronics.com

Contact No.: +91 9555245245

(Working Hours: Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management E: info@3rrecycler.com

For E-Waste & ROHS compliance refer to www.portronics.com/ewaste

