



Zeno Pulse

Handheld Massager Gun



User Manual

PRODUCT OVERVIEW

Thank you for choosing Portronics Zeno Pulse — your compact yet powerful solution for on-the-go muscle recovery. This user manual will guide you through the features, attachments, charging instructions, and safety precautions of your new mini massager. We recommend reading it thoroughly to make the most of your device.

SAFETY MEASURES

- Do not reach for massager if it has fallen into water, unplug immediately if charging.
- Do not use while bathing, in shower, or outside in inclement weather.
- Do not place or store massager where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not use massager without attachments.
- Do not carry massager by charging cable or use cable as a handle.

- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use this massager for more than 20 minutes at a time.
- Do not use massager in close proximity to loose clothing, jewelry and long hair.
- Never drop or insert objects into any openings on the massager.
- Never operate massager if it has a damaged charging cable, if it is not working properly, if it has been dropped or damaged, or dropped into water.

WHAT IS IN THE BOX

Zeno Pulse 1 N
Massage Heads 5 N
USB Cable 1 N
User Manual 1 N

PRODUCT DETAILS

Massagers can provide a relaxing full body massage. The six speed shifting function allows you to adjust the massage intensity from light to heavy. Five different shapes of massage heads allow you to switch and enjoy highly customized professional quality massage at home.



Finger pressure massage head
Suitable for relaxing the whole body

Cloud massage head
Suitable for back pressure massage

Smooth massage head
Suitable for the whole body

Wave Massage head
Suitable for Soft Tissue

Spherical massage head
Seven circular beads combined with gold oil suitable for the whole body

PRODUCT SPECIFICATION

- Product Material: ABS
- Rated Voltage: 7.4V
- Charging Input: 5V/2A
- Charging Time: About 3 hours
- Usage Duration: About 40 minutes (maximum strength) / Medium gear can be used for about 1 hour
- Smart Timer: 10 minutes
- Battery Capacity: 2000mAh
- Motor Speed: 1700-3800r/min
- Functions: Kneading / Tapping / Pushing / Vibration Integration
- Rated power: 24W

USE IT THE WAY YOU WANT

- Mobility & Flexibility
- Pre-workout warm-up
- Post-workout recovery
- Sore muscle relief
- Improved Blood Circulation
- Joint pain relief
- Myofascial release
- Trigger point massage
- Relaxation

USAGE

1. Long press the power button to start, short press to display the battery level.
 2. After startup, click the button to increase the gear.
 3. When the maximum gear is reached, long press to shut down.
 4. Automatically shut down after 10 minutes of use.
- Before discarding the appliance, the battery must be removed from the appliance; When removing the battery, the appliance must be powered off first, and the battery should be safely disposed of.

The device has a hot compress surface, and people who are not sensitive to heat must be careful when using it. Remember not to use it while charging. This device is suitable for children aged 8 and above, as well as individuals with limited physical, sensory, or mental abilities or lacking relevant experience and knowledge, provided that they receive appropriate supervision or guidance while using the device and understand the dangers involved.

Children are not allowed to use this device. Without supervision, children are not allowed to perform cleaning and user maintenance operations. This device can only be supplied with the safety ultra-low voltage corresponding to its label.

- 5 different massage heads
- Small and portable
- 6-level intensity adjustment
- Type c charging
- Protective netting to prevent hair from getting caught

MAINTENANCE TIPS

To keep this device in its pristine condition, wipe its surface with a slightly damp towel and dry it with a soft cloth. Keep the device away from liquids and heat. "If the device is not used for a long time, it must be charged once every 3 months, otherwise it will reduce the battery life of the product.



E-Waste Management
E: info@3recycler.com
For E-Waste & ROHS compliance refer to www.portronics.com/ewaste

www.portronics.com

For Support
Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(Working Hours. : Monday - Saturday 10:00am - 6:00pm)