



ZUNO | 2.1 Channel Home Theatre
With Wired Sub Woofer

USER MANUAL

What is in the box

- | | |
|------------------|--------------------|
| 1. Subwoofer 1 N | 4. Aux Cable 1 N |
| 2. Soundbar 1 N | 5. Adaptor 1 N |
| 3. Remote 1 N | 6. User Manual 1 N |

Specification

- Output Power – 100W
- Speaker Size: 2.25" x 2
- Sub Woofer Size- 4" x 1
- Bluetooth Version – 5.3
- Frequency Response: 35Hz-20kHz
- Product Dimension: Soundbar :410*90*68.5mm
: Subwoofer: 335*120*200mm

Power & Standby

- When connected to a DC power source, the speaker enters standby mode.
- A red light appears between the "+" and "M" buttons.
- Press and hold the Mode (M) button for 2 seconds to turn ON. A beep will sound and a blue light indicates Bluetooth mode.

Switching Modes

Short-press the Mode (M) button to switch modes:

- Bluetooth (BT) – Blue light
- USB – Green light
- HDMI – Cyan light
- AUX – Red light

Bluetooth Mode Controls

1. "-" button:
 - Long press: Previous track
 - Short press: Volume down
2. "+" button:
 - Long press: Next track
 - Short press: Volume up
3. Volume max alert: "chi-chi" sound



- "-" Button (Minus)
- Play / Pause Button
- "+" Button (Plus)
- "M" Button (Mode)
- Light / LED Button

Type-C

1. "-" button:
 - Long press: Previous track
 - Short press: Volume down
2. "+" button:
 - Long press: Next track
 - Short press: Volume up
3. Volume max alert: "chi-chi" sound
4. Light flashes purple in USB mode

AUX Mode Controls

1. "-" button:
 - Long press: Not functional
 - Short press: Volume down
2. "+" button:
 - Long press: Not functional
 - Short press: Volume up
3. Red light flashes in AUX mode

Play / Pause Button

1. Bluetooth mode:
 - Short press: Play/Pause
 - Long press: Pair/Disconnect Bluetooth
2. USB mode:
 - Short press: Play/Pause
3. AUX mode:
 - Short press: Mute/Unmute

LED Light Effects

1. When DC power is connected:
 - Side lights turn on (single color)
 - Front RGB light bar auto-switches and flashes.
 - During music playback, RGB lights flash left to right with rhythm.
2. Light Button Functions:
 - Press once: Red, Green, Blue slow breathing effect
 - Press twice: Blue, Cyan, Green, Yellow, Red, Purple marquee animation.
 - Press 3 times: Solid Blue light
 - Press 4 times: Solid Green light
 - Press 5 times: Solid Purple light
 - Press 6 times: Turns OFF all lights

Ports Details

- | | |
|----------------------------|------------------------|
| 1. Ports Details | 4. HDMI |
| 2. AUX (3.5mm Audio Input) | 5. SUB (Subwoofer Out) |
| 3. USB-C Port | 6. DC (Power Input) |



- Button (-): Long press for previous track, short press for volume down.
- Button (+): Long press for next track, short press for volume up.
- LED flashes during operation.
- A 'chi-chi' alert sound indicates maximum volume.