PORTRONICS

BEEM 570

Smart LED Projector With Adjustable Angle

User Manual

NETFLIX YouTube prime video Jaimovie

Safety Instructions

Read all instructions before you use this device. Do not make any changes or create settings that are not mentioned in this manual. Any damages or injuries or data or damage is caused by failure to follow instructions, the warranty does not apply.

1. To reduce the risk of fire or electric shock, do not expose the device to rain or moisture. Objects filled with liquids, such as vases, should not be placed on the device.
2. Do not place this device on soft surfaces such as tablecloths or carpets, otherwise the device could be a fire hazard.
3. Do not place this device in areas susceptible to excessive dust and dirt or near any appliance producing a strong magnetic field.
4. To prevent overheating, do not block or clog the ventilation holes.
5. Place the main device in a confined space. Always leave enough space around the device for ventilation.
6. Protect this device from overexposure to direct sunlight, high temperature, strong vibrations and moisture. Avoid outdoor temperature.
7. When this device is running for a long period of time, it will become hot. Allow it to cool before disconnecting and unplug the charger. Resume operation after this device has cooled down.
8. Do not touch the lens with a pen. Avoid touching the lens. Do not allow children to handle the device without supervision.
9. Use attachments or accessories specified by the manufacturer only.
10. Avoid extreme vibration as it may damage the internal components.

Package List

Projector × 1

Remote Control × 1
(Batteries are not included)

Power Cable × 1

HDMI Cable × 1

User Manual × 1

Overview

Remote Control

Note: the matching interface of Bluetooth remote control. Press Voice search button to bring up the matching guide.

Bluetooth remote controller pairing:
Please keep the Remote Controller within 10 meters of the projector. Press and Hold Left button and Right button for three seconds to pair.

Getting Started

Plug the power cable to the projector.
Press power button to turn on the projector.

Use the manual focus by pressing the "Focus" button on the remote control.

Tips:
Make sure the projector is horizontal to the projector screen.

Cleaning Method

Pry off the side cover.

Clean the projector by the cotton swab.

Reinstall the side cover after cleaning.

Network Setting

①Click Setting icon on the homepage - Setting - Network - Wi-Fi - Connect to Network → Choose the network and type the password that you want to connect to.

Bluetooth Setting

①Click Setting icon on the homepage - Setting - Bluetooth - Pair Bluetooth → Bluetooth devices →Click search and pair the device that you want to connect to.

CEC Setting

①Click Setting icon on the homepage - Setting - Network - HDMI CEC - CEC → Enable CEC, CEC devices such as TV sticks can be controlled remotely with remote control.

Picture Setting

①Click Setting icon on the homepage - Setting - Picture - Picture Mode, adjust picture settings, change picture mode, set eye protection mode.

Sound Setting

①Click Setting icon on the homepage - Setting - Sound - Set the sound quality balance of the machine sound, adjust the sound mode, choose the output device and output format of the sound.

Lens Setting

①Click Setting icon on the homepage - Setting - Lens - Adjust the lens keystone, autofocus, keystone correction, digital zoom.

Device Preference

①Click Setting icon on the homepage - Setting - Device Preference→Change language, set date and time, choose keyboard, change device mode, set screen saver and sleep time, set power on mode, set power off mode, set projector, whether OS cast, set energy, save menu, times

Whale OS Cast

②Connect your phone and the projector to the same network.
Enter to Setting - Device Preference -Whale OS Cast - TV Name, Enter the name of the projector, Ready to Pair
After installation, search and click the projector device on your phone to share screen.

App Setting

①Click Setting icon on the homepage - Setting - App Setting - Check recently opened applications, view all applications, and app permissions.

Voice Service

①Click Setting icon on the homepage - Setting - Voice Service - Set voice recognition and timbre of intelligent speech can be adjusted.

Software Update

①Click Setting icon on the homepage - Setting - Software Update - Upgrade software and view the current software information.

File Management

①Insert the U-disk, click the File icon on the homepage. Supported file types that could be read, such as video, audio,picture, etc.

Bluetooth Speaker

①Click Bluetooth Speaker icon on the remote , click to enter the Bluetooth speaker mode.
Search for machine name on your mobile phone, and then pair connection.
Click +/Turning off the screen to turn off the screen, and press the back button to exit the screen off state.

Bluetooth Speaker

Signal Source

①Click Signal Source icon on the homepage, choose HDMI Signal Source.
Search for machine name on your mobile phone, and then pair connection.
Click +/Turning off the screen to turn off the screen, and press the back button to exit the screen off state.

Advisory for Safe Projector Use

Maintain Minimum Distance

- Keep the projector at least 20 cm away from any wall. This ensures adequate proper airflow and prevents overheating.

Why This Is Important

- Ensures efficient cooling and avoids heat buildup.
- Reduces risk of damage to internal components.
- Maintains optimal projection image quality.
- Extends overall projector lifespan.

Additional Safety Tips

- Do not block ventilation grills.
- Avoid placing the projector inside closed cabinets without ventilation.
- Keep the projector on a stable, flat surface.
- Ensure the surrounding area is clean and dust-free.

PORTRONICS

www.portronics.com

For Support
Mail : www.portronics.com
Call : 1800-103-0000(Toll-free)
Contact Us: +91 9555402400
(**Working Hours** : Monday – Saturday, 9:00am – 6:00pm)

E-Waste Management
E: info@beetel.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste