PORTRONICS

BUBBLE 2.0



WIRELESS KEYBOARD WITH
2.4 GHZ RECEIVER & BLUETOOTH

User Manual

What's Inside The Box

1 x Wireless Keyboard
1 x USB Receiver
1 x User Manual
2 x AAA Batteries

Getting Started

1. To begin using your wireless keyboard, locate the battery compartment lid at the back side of the device.
2. Gently remove the lid to access the battery compartment, and then insert 2 AAA batteries (batteries included) following the polarity (+ and -) markings inside the compartment.
3. Ensure the batteries are properly aligned, and after inserting them, securely place the battery compartment lid back in its original position.

Powering On / Off

1. Locate the power slide button at the top/upper side of the keyboard.
2. Slide the button to the 'On' position.
3. Your wireless keyboard is now ready for use.
4. When you're finished using the keyboard or want to conserve battery power, slide the power button to the 'Off' position.

2.4 GHz Mode Setup

- Locate the battery compartment at the back side of the keyboard.
- Carefully remove the battery compartment lid.
- Inside the battery compartment, you will find the 2.4 GHz USB receiver. Gently remove it.
- Insert the 2.4 GHz USB receiver into your device's USB port.
- Turn on the keyboard by sliding the power button to the 'On' position (if applicable).
- Press the F10 (2.4G) key located at the upper right side of the keyboard.
- Upon pressing the F10 (2.4G) key, the indicator light above it will turn on for 2-3 seconds and then turn off.
- Your wireless keyboard is now ready to use in 2.4 GHz mode.



Bluetooth Pairing

Bubble 2.0 allows you to connect two devices via Bluetooth, one through BT1 and the other through BT2. Follow similar instructions below to connect a device via BT2.

1. Turn on the keyboard by sliding the power button to the 'On' position.
2. Press the F11 (BT1) key and the indicator light above BT1 will turn on.
3. Long press the BT1 key till the indicator light begins flashing. The keyboard has now entered Bluetooth Pairing Mode.
4. On your device (e.g., laptop, tablet, or smartphone), go to the Bluetooth settings.
5. Enable Bluetooth on your device if it's not already on.
6. In the Bluetooth settings, scan for available devices.
7. When you see 'Bubble 3.0' or 'Bubble 5.0' listed, select it to initiate pairing.
8. Once paired successfully, a confirmation message will appear on your device.
9. Your wireless keyboard is now connected via Bluetooth and ready to use.

Note: If you press a key on the keyboard and the indicator above BT1 blinks 5 times, this indicates that the Bluetooth has disconnected.



Multi-Device Connectivity

1. Bubble 2.0 offers three distinct connectivity channels: 2.4GHz, Bluetooth 1 (BT1), and Bluetooth 2 (BT2). This enables seamless usage with up to three different devices, including desktops, laptops, mobile phones, and tablets, without any confusion.
2. To initially connect a device, long press any channel button - F10 (2.4 Ghz), F11 (BT1), or F12 (BT2) for 3 seconds. The connection process is similar to the one described above.
3. Once the device is successfully connected, you can proceed to add additional devices.
4. After connecting three different devices to their respective channels, if you wish to switch between them, simply press the corresponding channel button for 1 second.
5. The indicator light will illuminate for 3 seconds and then turn off.
6. This indicates that the channel switching is complete, and you can now use the keyboard with the selected device.



Press Easy-Switch button for 1 second,
(Blinking light means the keyboard is ready for pairing.)



Steady Light for 3 seconds indicates successful pairing.

Quick Function

esc	Lock switch F1-F12 and multimedia	F1	Decrease brightness	F2	Increase brightness	F3	Mission control
F4	Previous piece	F5	Play/Pause	F6	Next track	F7	Mute
F8	Volume down	F9	Volume up		Calculator	delete	Delete

Multimedia Switch

F1-F12 Switch fn + esc

- Default mode: The multimedia buttons at the top of the front row perform their standard functions. You can easily switch among them by pressing the buttons directly.
- To access the functions on the bottom of the F1-F12 keys, press Fn + Esc together to activate function lock. You will now be able to use the top row as function buttons.
- To return to default mode press the Fn + Esc again, allowing you to switch between 2.4G, BT1, BT2, and multimedia key functions.

Low Battery Warning

When the battery power is too low, the battery is in a state of low voltage. The battery symbol indicator lights will flash a red light as an alarm, indicating the need to replace the battery promptly to continue use.

Technical Specifications

Wireless Mode	2.4 GHz & Bluetooth 5.3
Batteries	2 x AAA Batteries (included)
Key Life	10 million keystrokes
Working Distance	10 metres
Compatible Operating Systems	Windows 8.1 & higher macOS X 10.4 & higher iOS 12 & higher
Dimensions (mm)	314 x 124 x 22
Weight	375 grams

Please note: Any damage caused by physical impact, water / liquid, fire, etc. caused by the customer or nature shall not be covered under warranty. Only product design, feature and functionality-related faults can be considered. During the warranty period, this product is only eligible for replacement and not eligible for repair, as per the brand's discretion.

Switching OS Compatibilty

The Bubble 2.0 wireless keyboard features Windows, macOS and iOS modes to ensure compatibility with your device (laptop, smartphone, tablet, etc.).

- Windows Mode: Press Fn Key + P to switch to Windows compatibility
- macOS Mode: Press Fn Key + O to switch to macOS compatibility
- iOS Mode: Press Fn Key + I to switch to iOS compatibility

Do's and Don'ts

- The device's battery life varies by battery brand, usage, and environmental factors. We recommend using heavy-duty AAA batteries from reputable brands.
- Ensure the device remains dry and is shielded from rain, humidity, liquids, and condensation.
- Store the equipment within moderate temperature ranges; avoid high or low extremes.
- Do not use the device with wet hands.
- Do not use or store the device in dusty or dirty areas.
- Do not drop, knock or shake the device.

www.portronics.com
For Support
Visit : www.portronics.com
E-mail : help@portronics.com
Contact No.: +91 9555245245, 011-42413131
(**Working Hours.:** Monday - Saturday, 10:00am - 6:00pm)

E-Waste Management
E: info@3rrecycler.com
For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste