Size=503 x 84 mm (Front)

PORTRONICS

HARMONICS PRIME

Wireless Stereo Headset



User Manual

PACKAGE CONTAINS

- Harmonics Prime 1N
- Charging Cable 1N
- User Manual 1N
- Extra Eartips 2 N

SPECIFICATIONS

- Dual pairing: Yes
- Driver: 10mm
- Supported profile: HFP, A2DP, HSP, AVRCP
- Bluetooth version: 6.0
- Neckband charging time: Up to 60 minutes
- Stand by time: 300 Days
- Playtime: Up to 50 hours @ 60% volume
- EQ modes: 3 Inbuilt EQ Modes
- Bluetooth range: 10m
- Water resistance: IPX5
- Fast Charging- Charge for 10 mins, use for 10 Hours

POWER ON

Long press the multifunction button for 3 seconds, the red and white LED will blink alternatively for 1 second indicating that it's powered on.

POWER OFF

Long press the multifunction button for 3 seconds, the red and white LED will blink alternatively for 1 second indicating it's powered off.

Long press for 3 seconds



POWER ON
(indication)

POWER OFF
(indication)

PAIRING

- Long press the multifunction button for 3 seconds, the device will be in pairing mode once powered on.
- Red and white LED will flash alternately indicating the device is in pairing mode.
- Turn on the Bluetooth on your smartphone or laptop and open the Bluetooth menu.
- Select 'Add Device' and from the list of devices select 'Portronics Harmonics Prime'.
- The White light flashes 2 times every 4 seconds indicating that your neckband is paired.

  Note: The device will automatically turn off if not connected within 5 minutes.



RESET

- Please reset the device, if you are having trouble connecting or using your Harmonics Prime.
- Before resetting, make sure that your device is fully charged.
- Press and hold the Mode button for 8 second, when power is on or device is connected.
- The red and white LED will flash 3 times, indicating that Portronics Harmonics Prime has been reset.



Press the Mode button for 8 seconds
(indication)

DUAL PAIRING

- Connect your Harmonics Prime with Device 1.
- Turn off the Bluetooth of Device 1, and connect Harmonics Prime with Device 2.
- Turn on Bluetooth of Device 1, both the devices will be paired and are ready to use.

CHARGING

Plug the Type-C cable to the charging port of the neckband.

On charging mode, LED will be in solid red.

- **Solid red LED** — Charging

Once charged, LED will be in solid white.

- **Solid white LED** — Fully Charged

Size=503 x 84 mm (Back)

CONTROLS

Play/Pause
Press the multifunction button once



Short Press

Previous Song
Long press -



Long press -

Next Song
Long press +

Long press +

Volume Up
Short press +

Short press +

Volume Down
Short press -



Short press -

Answer/End a Call
Short press the multifunction button once



Reject Call
Long press the multifunction button for 2 seconds



Long press for 2 seconds

Voice Assistant
Press the multifunction button thrice

Press thrice

Gaming Mode
Long press the mode button for 2 seconds



Long press for 2 seconds

Switch Call
Long press the multifunction button for 2 seconds



Long press for 2 seconds

EQ Mode
Short press the mode button to switch between the 3 EQ modes



Short press

SAFETY FOR YOU AND YOUR NOISE AIRWAVE

Follow these tips to get best out of your new Harmonics Prime

- Do not expose the neckband to liquids, moisture or humidity as they have electronics and battery inside.
- Don't use abrasive cleaning solvents to clean your new neckband. Wipe them down with a slightly damp cloth if and when necessary.
- Remove and clean the earbud tips regularly to ensure that you always enjoy the best sound possible.
- Do not expose the neckband to extremely high or low temperature as this may damage the battery or even deform the plastic parts.
- Don't throw the neckband in a fire to dispose it. The internal battery may explode.
- Don't try to disassemble your neckband. There are no user serviceable parts inside it.
- Try not to drop the neckband and keep them away from sharp objects such as keys in your pockets.
- Only charge your neckband from 5V USB ports such as phone chargers and laptops or PCs
- Never listen to music at high volume or you may permanently damage your hearing.
- Pay attention to your surroundings and never wear any earphones while riding, driving or walking in traffic.

PORTRONICS

www.portronics.com

For Support

Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(Working Hours : Monday - Saturday, 10:00am - 6:00pm)

E-Waste Management
E: info@3recycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste