PORTRONICS

MOPCOP DUO

3-in-1 Cordless Vacuum Cleaner, Air Blower & Floor Mop



User Manual

Product Overview

The Portronics MopCop Duo is a 3 in 1 cleaning solution designed for quick and efficient everyday cleaning. Equipped with multiple cleaning attachments, dual-speed modes, washable filters, and Type-C charging support. Read this manual to know more about it's functions.

Product Description





Assembly Instructions

Step 1: Connect and tighten the upper and lower sections of the metal tube.



Step 2: Insert the metal tube into the main body securely.



Step 3: Fix the floor brush/mop head to the bottom of the mop body.



Step 4: Insert the vacuum unit into the mop body make sure it is locked properly.



How to Use

Power ON / OFF

- Long Press the Power/Mode Button to turn ON the device.
- Single Press to switch between two cleaning modes.
- Single Press again to turn OFF the device.

AS A VACUUM:

- Use only the provided nozzle attachments if needed while using the vacuum cleaner.
- Set the suction level accordingly.

AS A MOP:

- To use the device as a mop, turn OFF the vacuum and remove the nozzles if attached.
- Place the vacuum unit into the mop's body carefully and turn ON the device to use it as a mop.
- Make sure that the parts of the mop are attached properly as in the assembly instructions.
-

AS A BLOWER:

- To use it as a blower, attach the respective blower nozzles into the bottom of the vacuum unit.
- While using the device as a blower remove the dust cup and filter for better performance.



Speed Indicator Lights

- Low-Speed Mode - Blue Light
- High-Speed Mode - White Light

Dust Cup Cleaning

To Empty the Dust Cup

- Press the dust release button.
- Rotate and pull down the dust cup.
- Remove the filter assembly carefully.
- Dispose of collected dust and debris.



Cleaning the Filter

- Remove the metal filter and sponge filter.
- Wash with clean water only
- Allow all parts to dry completely before reinstalling.
- Installing wet filters may damage the product.



Charging

- Remove the main unit from the body before charging.
- Use the supplied Type-C charging cable.
- Low Battery- Flashes Orange
- While Charging - Flashes Blue
- Once fully charged, the light turns OFF automatically.



Product Specifications

- Working Wattage - 110W
- Suction Power - Max 17KPa / Min 8KPa
- Runtime - Up to 30 Minutes (Low Speed)
- Dust Cup Capacity - 90ml
- Battery Capacity - 3 × 2000mAh
- Charging Port - Type C
- Charging Input - 5V/2A
- Charging Time 4–5 Hours

Safety Instructions

- Use the product indoors only.
- Do not expose the device to water or excessive moisture.
- Do not use the product to clean liquids or wet surfaces.
- Avoid vacuuming sharp, burning, or flammable objects.
- Keep the product away from high temperatures and heating equipment.
- Do not touch the charger or device with wet hands.
- Use only official or included accessories.
- Do not block the air vents during operation.
- Keep away from children and do not allow them to play with the product.
- Do not disassemble or modify the product yourself.

Error & Protection Indicators

Condition	Indicator Behavior
High Temperature	Yellow light turns OFF for 3 seconds
Low Voltage Protection	Orange light flashes
Charging Error	Yellow light flashes repeatedly
Battery Protection Active	Device shuts down automatically

These protection features help ensure safe operation and battery life.

PORTRONICS

www.portronics.com

For Support

Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(**Working Hours :** Monday - Saturday, 10:00am - 6:00pm)

E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance refer to www.portronics.com/ewaste