


Fix the outer stand to the wireless charger device holder.






Press the key button and attach car mount on an appropriate place.



Connect the cable to the base socket and the other end to the charger adapter.



Put you device on the holder and it will be automatically locked by holder.



4) 360° rotating, you could adjust your phone to the best position.



IMPORTANT SAFETY INSTRUCTIONS When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However improper use can result in potential electrical shock or fire hazards, Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all

warnings listed in these instructions and on the unit. 1. Water and Moisture - The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink

WARNING/DISPOSAL OF UNIT

Please do not attempt to change the parts yourself.

concerning battery/electronics disposal.

Never dispose of used batteries/electronics with ordinary solid

wastes, since they contain toxic substances. Always dispose of used batteries/electronics in accordance with the prevailing regulations that apply to the disposal of batteries/electronics. If there are no local regulations

please dispose of the device in a waste bin for electronic

CAUTION

substance.

Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic

Always confirm that the temperature is 5°C - 50° C before you charge the battery.

Always keep the unit out of the reach of infants and small

children.

damp cloth. Do not use solvents, etc. Objects and Liquid Entry – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product. 8. Attachments - Do not use attachments not recommended by the product manufacturer.

> 9. Overloading - Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result

> > in a risk of fire or electric shock. 10. Damage Requiring Service - The unit should be serviced

> > 2. Ventilation - The unit should be situated so that its

laundry tub, swimming pool or in a wet basement,

location or position does not interfere with its proper

ventilation. For example, it should not be situated on a bed.

sofa, rug or similar surface that may block ventilation

openings. Also, it should not be placed in a built-in

installation, such as a bookcase or cabinet, which may

3. Heat - The unit should be situated away from heat

sources such as radiators, heat registers, stoves or other

4. Power Sources - The unit should be connected to a power supply only of the type described in the operating

5. Power-Cable Protection - Power supply cables should be

routed so that they are not likely to be walked on or pinched

by items placed upon or against them. It is always best to

have a clear area from where the cable exits the unit to

6. Cleaning - The unit should be cleaned only using a warn

impede the flow of air through the ventilation openings.

appliances (including amplifiers) that produce heat,

instructions or as marked on the appliance.

where it is plugged into an AC socket,

- A. the power supply cable or plug has been damaged. B, objects have fallen into or liquid has been spilled into the enclosure.
- C, the unit has been exposed to rain.

by qualified service personnel when:

- D, the unit has been dropped or the enclosure damaged. E, the unit exhibits a marked change in performance or does
- not operate normally. 12 Periods of Nonuse - If the unit is to be left unused for an
- extended period of time, such as a month or longer, the power cable should be unplugged from the unit to
- 13. Servicing The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

Specifications:

Product Weigh

Product Size

prevent damage or corrosion.

: Micro USI Connector Type 9V/5V 1.67A/2A Charging Voltage Charaina Current 110KHz-205KHz Working Power 10W/7.5W/5W Charging Efficiency : Around 75%

: 119 X 111 X 47mm

Get Free Extra Warranty visit: www.portronics.com/register-warrenty.htm (() () () () E-waste Managemen Email - info@3rrecycler.com For E-weste & ROHS compliance refer

www.portronics.com

Email: supportcenter@portronics.com Contact No.: +91 9555245245 . 011-4241313

(Working Hrs.: Monday - Saturday 10:00am - 6:00pm