



Power Shutter Air 5K

Wireless Magnetic Powerbank



User Manual


INTRODUCTION

Thank You For Purchasing Power Shutter Air 5K Power Bank by Portronics! This 20W device charges your smartphones and USB devices on the go with a sleek design and LED Indicator. This manual covers its features and usage. Thanks for choosing Portronics!

PACKAGE CONTAINS

- Powerbank X 1 N
- USB Charging Cable X 1 N
- User Manual X 1 N

PRODUCT OVERVIEW



TECHNICAL SPECIFICATIONS

Battery : Li-Polymer
Battery Power : 5000mAh
Input : Type-C
Output : Type -C and Wireless Charging
Type-C Input : 5V --- 3A, 9V --- 2A
Type-C Output : 5V --- 3A, 9V --- 2.22A, 12V --- 1.67A, 10V --- 2.25A
Type C PPS : 5.0-11.0v --- 2.2A
Wireless Output : 5W/7.5W/10W/15W
Product size : 98 x 67 x 20mm (without cable)




INSTRUCTIONS

1. CHARGING YOUR POWERBANK

To charge your power bank, connect the Type-C port located on the power bank to a USB-A port or USB-C charger using the provided charging cable. Once charging begins, the LED Indicator will blink.

Percentage	LED 1	LED 2	LED 3	LED 4
0 - 25%	Blinking	Off	Off	Off
26 - 50%	On	Blinking	Off	Off
51 - 75%	On	On	Blinking	Off
76 - 100%	On	On	On	On
Abnormal	Blinking	Blinking	Blinking	Blinking




2. USING THE POWER BUTTON

- A button is located on the bottom of the Power Bank.
- Press the button once to turn on the power bank and view the remaining battery capacity on the LED Indicator.

3. CHARGING YOUR MOBILE PHONE

To charge your mobile phone using the power bank, simply connect your device using Type -C Port with the provided charging cable.




WIRELESS CHARGING

To charge a magsafe wireless mobile using wireless charging-enabled device, simply place it on the designated wireless charging area of the power bank. Charging will begin automatically.

WIRELESS CHARGING TIPS

- Place your wireless charging-enabled device within the designated wireless charging area of the power bank (refer to the diagram for the location of the wireless charging coil).
- Adjust the position of your device to ensure it is within the wireless charging range for optimal performance.



(✓)

(✓)

(✗)

1. STORAGE

- **Keep Away from Extreme Temperatures** : Store your power bank in a cool, dry place. Avoid exposing it to direct sunlight, high heat (e.g., inside a car on a hot day), or freezing temperatures, as these can damage the battery or cause it to leak.
- **Partial Charge for Long-Term Storage** : If you won't use it for a while, charge it to about 50-60% before storing. A fully charged or completely drained battery can degrade over time.
- **Avoid Moisture** : Keep it away from water or humid environments to prevent short circuits or corrosion.

2. HANDLING

- **Inspect for Damage** : Regularly check for signs of wear, such as a swollen battery, cracked casing, or exposed wires. If you notice any damage, stop using it immediately and dispose of it safely.
- **Don't Drop or Crush** : Physical damage can rupture the battery, leading to leaks or even a fire hazard.
- **Keep Away from Metal Objects** : Store it away from coins, keys, or other metal items that could accidentally connect the terminals and cause a short circuit.

3. SAFETY PRECAUTIONS

- **Avoid Overheating** : If the power bank feels unusually hot during use or charging, unplug it and let it cool down before using it again. Persistent overheating is a sign of a problem.
- **Don't Disassemble** : Never attempt to open or repair a power bank yourself. Internal components like lithium batteries can be dangerous if mishandled.

4. DISPOSAL

Proper Recycling : When your power bank reaches the end of its life, don't throw it in the trash. Take it to an electronics recycling center, as lithium batteries can be hazardous if improperly disposed of.

CHARGING AND USAGE

- **Use the Right Cable and Charger** : Always use the cable provided by the manufacturer or a compatible, high-quality alternative. Cheap or damaged cables can overheat or cause short circuits.
- **Avoid Overcharging** : Most modern power banks have overcharge protection, but it's still a good idea to unplug them once fully charged to prevent strain on the battery.

- **Don't Charge and Discharge Simultaneously** : Avoid using the power bank to charge your devices while it's being charged itself, as this can generate excessive heat and degrade the battery.
- **Charge in a Safe Environment** : Place the power bank on a flat, non-flammable surface while charging. Avoid charging it on beds, sofas, or near flammable materials.

WHERE NOT TO KEEP YOUR POWER BANK

- **On a Bed During Sleep** : Placing a power bank on a bed while sleeping can trap heat, especially if it's under a pillow or blanket, increasing the risk of overheating or fire.
- **Inside a Pocket or Bag with Metal Objects** : Storing it with keys, coins, or other metal items can cause a short circuit if they contact the ports.
- **Near a Heater or Radiator** : Heat sources can raise the power bank's temperature beyond safe limits, damaging the battery.
- **On a Couch or Cushion** : Soft surfaces can block ventilation, leading to heat buildup if the power bank is still warm from use or charging.
- **In a Car Dashboard Under Sunlight** : Direct sunlight can push the temperature to dangerous levels, risking battery leakage or explosion.

HANDLING A SWOLLEN POWER BANK

If your power bank swells, stop using it immediately and unplug it carefully, placing it on a non-flammable surface away from flammable items, people, and pets to avoid risks like leaks or explosions. Do not puncture or open it; instead, let it cool down and dispose of it at an electronics recycling center per local rules—never in regular trash. Contact the manufacturer for further advice

IMPORTANT NOTE

The company will not be responsible for any damage, injury, or malfunction resulting from improper usage, mishandling, or failure to follow the manufacturer's instructions



E-Waste Management
E: info@3rrecycler.com
For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste

www.portronics.com
For Support
Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245
(Working Hours. : Monday -
Saturday 10:00am - 8:00pm)